Pioneer sound.vision.soul

EV5DVD

Stereo DVD Cassette Deck Receiver

XV-EV5

Speaker System

S-EV5V

EV7DVD

Stereo DVD Cassette Deck Receiver

XV-EV7

Speaker System

S-EV7V

EV9DVD

Stereo DVD Cassette Deck Receiver

XV-EV9

Speaker System

S-EV9V
















IMPORTANT



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION:

TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

D3-4-2-1-1 En-A

CAUTION

This product is a class 1 laser product, but this product contains a laser diode higher than Class 1. To ensure continued safety, do not remove any covers or attempt to gain access to the inside of the product. Refer all servicing to qualified personnel.

The following caution label appears on your unit.

Location: bonnet of the unit



Location: rear of the unit

CLASS 1 LASER PRODUCT

D3-4-2-1-8_A_En

WARNING

This equipment is not waterproof. To prevent a fire or shock hazard, do not place any container filed with liquid near this equipment (such as a vase or flower pot) or expose it to dripping, splashing, rain or moisture.

WARNING

Before plugging in for the first time, read the following section carefully.

The voltage of the available power supply differs according to country or region. Be sure that the power supply voltage of the area where this unit will be used meets the required voltage (e.g., 230 V or 120 V) written on the rear panel.

D3-4-2-1-4 A_En

WARNING

To prevent a fire hazard, do not place any naked flame sources (such as a lighted candle) on the equipment.

D3-4-2-1-7a_A_En

Operating Environment

Operating environment temperature and humidity: +5 °C to +35 °C (+41 °F to +95 °F); less than 85 %RH (cooling vents not blocked)

Do not install this unit in a poorly ventilated area, or in locations exposed to high humidity or direct sunlight (or strong artificial light)

D34-2-1-7c_A_En

Recording equipment and copyright: Recording equipment should be used only for lawful copying and you are advised to check carefully what is lawful copying in the country in which you are making a copy. Copying of copyright material such as films or music is unlawful unless permitted by a legal exception or consented to by the rightowners.

K018 En

VENTILATION CAUTION

When installing this unit, make sure to leave space around the unit for ventilation to improve heat radiation (at least 30 cm at top, 15 cm at rear, and 15 cm at each side).

WARNING

Slots and openings in the cabinet are provided for ventilation to ensure reliable operation of the product, and to protect it from overheating. To prevent fire hazard, the openings should never be blocked or covered with items (such as newspapers, table-cloths, curtains) or by operating the equipment on thick carpet or a bed.

D3-4-2-1-7b_A_En

CAUTION: USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE

SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

CAUTION: THE USE OF OPTICAL INSTRUMENTS WITH THIS PRODUCT WILL INCREASE EYE HAZARD. D6-8-2-1_En

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

D8-10-1-2 En

Information to User

Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.

D8-10-2_Er

CAUTION: This product satisfies FCC regulations when shielded cables and connectors are used to connect the unit to other equipment. To prevent electromagnetic interference with electric appliances such as radios and televisions, use shielded cables and connectors for connections. **D8-10-3a_En**

CAUTION

The STANDBY/ON switch on this unit will not completely shut off all power from the AC outlet. Since the power cord serves as the main disconnect device for the unit, you will need to unplug it from the AC outlet to shut down all power. Therefore, make sure the unit has been installed so that the power cord can be easily unplugged from the AC outlet in case of an accident. To avoid fire hazard, the power cord should also be unplugged from the AC outlet when left unused for a long period of time (for example, when on vacation).

If the AC plug of this unit does not match the AC outlet you want to use, the plug must be removed and appropriate one fitted. Replacement and mounting of an AC plug on the power supply cord of this unit should be performed only by qualified service personnel. If connected to an AC outlet, the cut-off plug can cause severe electrical shock. Make sure it is properly disposed of after removal. The equipment should be disconnected by removing the mains plug from the wall socket when left unused for a long period of time (for example, when on vacation).

This product is for general household purposes. Any failure due to use for other than household purposes (such as long-term use for business purposes in a restaurant or use in a car or ship) and which requires repair will be charged for even during the warranty period.

KO41 En


Voltage selector

You can find the voltage selector switch on the rear panel of multi-voltage models.

The factory setting for the voltage selector is 220 V to 230 V. Please set it to the correct voltage for your country or region.

• Saudi Arabia operates on 127 V and 220 V mains voltage. Please set to the correct voltage before using.

Before changing the voltage, disconnect the AC power cord. Use a medium size screwdriver to change the voltage selector switch.



D3-4-2-1-5_En

Thank you for buying this Pioneer product.

Please read through these operating instructions so that you will know how to operate your model properly. After you have finished reading the instructions, put them in a safe place for future reference.

Contents

| 01 Before you start | 06 Home theater sound |
|---|--|
| Checking what's in the box6 | About the listening modes23 |
| Loading the batteries | Auto listening mode |
| Range of the remote control unit 6 | Listening in surround sound23 |
| Attaching the non-skid pads | Using Front Surround 24 |
| Removing the speaker grilles | Using the Extra Power mode24 |
| | Listening in stereo24 |
| 02 Connecting up | Listening with headphones |
| Connecting the speaker terminals 8 | Lieterining With Headphorned IIIIIIII |
| Multichannel speaker connections 9 | 07 Disc playback features |
| Hints on speaker placement9 | Scanning discs |
| Attaching the surround speakers to the | Playing in slow motion |
| speaker stands10 | Frame advance/frame reverse |
| Optional surround speaker connections 10 | Playing a JPEG slideshow |
| Connecting the radio antennas 10 | Browsing DVD or Video CD/Super VCD discs |
| Connecting external antennas | with the Disc Navigator |
| Connecting to your TV | Browsing WMA, MP3, MPEG-4 AAC, |
| Connecting using the component | DivX video and JPEG files with the |
| video output | Disc Navigator27 |
| Connecting auxiliary components 12 | Looping a section of a disc |
| Connecting daxinary components | Using repeat play |
| Connecting the power | |
| 03 Controls and displays | Using random play |
| Front panel | Creating a program list |
| Display | Other functions available from the |
| Remote control | |
| Komote control | program menu |
| 04 Getting started | Using the front panel display29 |
| Setting the clock | Using Playlists |
| Using the remote to control your TV 17 | Programming playlists |
| Using the on-screen displays 17 | Listening to playlists |
| Playing discs | Clearing files from a playlist |
| Basic playback controls | Searching a disc |
| Resume and Last Memory | Switching subtitles |
| DVD-Video disc menus | Switching language / audio channels 31 |
| Video CD/Super VCD PBC menus 19 | Zooming the screen |
| Listening to the radio 20 | Switching camera angles |
| Improving FM stereo sound 20 | Displaying disc information31 |
| Listening to other sources 20 | 08 USB playback |
| Dimming the display | • • |
| Zimming the dioplay. | Using the USB interface |
| 05 Setting up for surround sound | Basic playback controls |
| Home theater sound setup | Scanning files |
| Setting the channel levels 21 | Playing a JPEG slideshow |
| Cottoning this original for love of the transfer to the | Browsing files with the Navigator33 |

| 09 Using the tape deck |
|---|
| Playing cassette tapes |
| Basic playback controls |
| Automatically recording CDs (ASES)35 |
| 10 More tuner features |
| Memorizing stations |
| Manually saving station presets |
| Listening to station presets |
| 11 Singing karaoke |
| Singing karaoke |
| Changing the vocal mix |
| 12 Adjusting the sound |
| Using the Sound menu |
| Using the Sound Field Control39 Boosting the bass level39 |
| Muting the sound |
| 13 Using the timer |
| Setting the wake-up timer |
| Setting the sleep timer |
| Setting the record timer41 |
| Turning the record timer on/off41 |
| 14 Audio Settings and Video Adjust |
| menu Audio Settings menu |
| Audio DRC |
| Virtual Surround |
| Video Adjust menu |
| 15 Initial Settings menu |
| Using the Initial Settings menu |
| Video Output settings |
| Display settings |
| Options settings |
| Parental Lock |
| Speaker Distance |
| |

| 16 Additional information |
|---|
| Optional system settings |
| System Setup menu options in standby48 |
| Disc / content format playback |
| compatibility49 |
| Disc compatibility table50 |
| About DVD+R/DVD+RW compatibility50 |
| About DivX 50 |
| About MPEG-4 AAC51 |
| About WMA51 |
| Using and taking care of discs52 |
| DVD Video regions52 |
| Handling discs52 |
| Storing discs |
| Discs to avoid |
| Using cassette tapes |
| Tapes you should avoid |
| Protecting your recordings52 |
| Installation and maintenance53 |
| Hints on installation53 |
| Cleaning the pickup lens |
| Problems with condensation53 |
| Moving the system unit |
| Screen sizes and disc formats |
| Resetting the system |
| Troubleshooting |
| DVD/CD/Video CD player |
| WMA/MP3/MPEG-4 AAC/JPEG discs 57 |
| Tuner |
| USB connection |
| Tape deck |
| Error Messages |
| Using the language code list |
| Language code list |
| Country/Area code list |
| Preset code list |
| Specifications |

Chapter 1 Before you start

Checking what's in the box

Please check that you've received the following supplied accessories:

- · Remote control
- Dry cell batteries (AA/R6) x2
- Video cord
- AM loop antenna
- FM antenna
- Power cord x1
- Speaker cords x1 (S-EV9V only)
- Speaker stands x2 (S-EV7V only)
- Non-skid pads x12 (S-EV7V only) / x4 (S-EV9V only)
- These operating instructions

Loading the batteries

Use AA/R6 batteries with the supplied remote control. Make sure to follow the indications $(\oplus$, \ominus) inside the compartment.





Incorrect use of batteries may result in such hazards as leakage and bursting. Observe the following precautions:

- Never use new and old batteries together.
- Insert the plus and minus sides of the batteries properly according to the marks in the battery case.

- Batteries with the same shape may have different voltages. Do not use different batteries together.
- When disposing of used batteries, please comply with governmental regulations or environmental public instruction's rules that apply in your country or area.
- Do not use or store batteries in direct sunlight or other excessively hot place, such as inside a car or near a heater. This can cause batteries to leak, overheat, explode or catch fire. It can also reduce the life or performance of batteries.

Range of the remote control unit

The remote control has a range of about 7 meters. It may not work properly if:

- There are obstacles between the remote control and this unit's remote sensor.
- Direct sunlight or fluorescent light is shining onto the remote sensor.
- This system is located near a device that is emitting infrared rays.
- This unit is operated simultaneously with another infrared remote control unit.

Attaching the non-skid pads

EV7DVD/EV9DVD model only

Use the self-adhesive non-skid pads to provide a stable base for the speakers. Attach four to each speaker or stand as shown below.





Center speaker

Surround speaker (EV7DVD only)

EV7DVD only – If you choose to use the Front surround 3-spot setup (as explained in Home theater sound setup on page 21), we recommend using the speaker stands provided (instead of attaching the pads to the base of the surround speakers). Using the speaker stands for the Standard surround 5-spot setup is optional. See Attaching the surround speakers to the speaker stands on page 10 for more on this.



Speaker stands

Removing the speaker grilles

If necessary, remove the front and (EV9DVD only) surround speaker grilles as described below.

- 1 Gently ease the grille loose by gripping the bottom and pulling towards you.
- 2 Pull the top free in the same way. When reattaching, start from the top then push the bottom in until secure.
 - It is not recommended (due to dirt and dust) to leave the speaker grilles removed.
 - Do not install your speakers overhead on the ceiling or wall. If improperly attached, the speaker grille can fall and cause damage or personal injury.

Chapter 2 Connecting up

Important

- · Before making or changing any connections, switch off the power and unplug the power cord from the AC outlet.
- When making cable connections, make sure not to bend the cables over the top of this unit. This may cause a humming noise from the speakers.

Connecting the speaker terminals

Connect the wires from the speakers to the terminals on the main unit rear panel as shown below. Before connecting, you may want to consider the placement options available in your room, and when using this system:¹

- EV5DVD model only Place the front left and right speakers at equal distances from the TV, then connect them as shown below. See Optional surround speaker connections on page 10 to connect surround speakers.
- EV7DVD/EV9DVD model only A color-coded system is provided for speaker connections (see Multichannel speaker connections below). See Home theater sound setup on page 21 for surround placement options.

Caution

- Do not connect this speaker to any amplifier other than the one supplied with this system. Connection to any other amplifier may result in a malfunction or fire.
- Make sure that the bare speaker wires cannot touch each other, or come into contact with other metal parts once the unit is switched on.

Twist and pull off the protective shields on each wire.



Connect to the speaker terminals on the rear of the unit.

Make sure to insert the red/colored wire into the red/colored (+) tab and the black/white wire into the black (-) tab.



• EV9DVD only - Connect the single end of the Y-cable to the **SUB WOOFER** terminal.



EV9DVD only: With the dual end of the Ycable, connect to the rear of each subwoofer in the same way.



Note


The speakers supplied with this system are magnetically shielded (except for the surround speakers, which should not be placed near a TV or monitor). However, placing them extremely close to a television may result in color distortion on the screen. If this happens, move the speakers a little further away and switch off the television for 15 to 30 minutes.

Multichannel speaker connections

EV7DVD/EV9DVD model only

Connect each speaker using the color-coded speaker cable. Match them to the colored labels above the speaker terminals (see illustration below).

• EV9DVD model only – Since there is only one terminal to connect the two subwoofers, you will need to use the supplied Y-cable for the connection.



Hints on speaker placement

The following guidelines will help you to get the best performance from your speaker system. See *Home theater sound setup* on page 21 for surround placement options with this system.

- Place the front left and right speakers at equal distances from the TV.
- Place the center speaker above or below the TV so that the sound of the center channel is localized at the TV screen.
- If possible, place the surround speakers slightly above ear level.

Caution

- These speaker terminals carry
 HAZARDOUS LIVE VOLTAGE. To prevent
 the risk of electric shock when connecting
 or disconnecting the speaker cables,
 disconnect the power cord before touching
 any uninsulated parts.
- If you choose to install the center speaker on top of the TV, be sure to secure it with putty, or by other suitable means, to reduce the risk of damage or injury resulting from the speaker falling from the TV in the event of external shocks such as earthquakes.

Connecting up


- Try not to place the surround speakers further away from the listening position than the front and center speakers. Doing so can weaken the surround sound effect.
- Make sure all speakers are installed securely to prevent accidents and improve sound quality.
- Do not attach these speakers to the wall or ceiling. They may fall off and cause injury.

Attaching the surround speakers to the speaker stands

EV7DVD model only

If you have set up your system using the Front surround 3-spot setup (as explained in *Home* theater sound setup on page 21), it is necessary to use the speaker stands provided. Using the speaker stands for the Standard surround 5spot setup is optional. Attach each speaker as shown in the steps below.

- Line up the spurs on the speaker stand with the holes on the back of the surround speaker and press into place.
- With the spurs fixed in place, pull the speaker downward to secure it on the stand.



Optional surround speaker connections

EV5DVD model only

Using RCA speaker cables, you can connect surround speakers to the left and right **SURROUND** speaker jacks on the rear panel for multichannel sound from this system. For the best surround effect, place the

surround speakers slightly above ear level and at the same distance from the listening position as the front speakers.


Important

- Use speakers with a nominal impedance of at least 16 Ω .
- Make sure you connect both surround speakers or you won't be able to hear anything from the surround jacks.



Connecting the radio antennas

Connecting the supplied antennas will allow you to listen to both AM and FM radio broadcasts. If you find that reception quality is poor, an outdoor antenna should give you better sound quality—see Connecting external antennas below for more on how to do this.



Connecting up

- 1 Pull off the protective shields of both AM antenna wires.
- 2 Push open the tabs, then insert one wire fully into each terminal, then release the tabs to secure the AM antenna wires.

3 Fix the AM loop antenna to the stand.

To fix the stand to the antenna, bend in the direction indicated by the arrow (*fig. a*) then clip the loop onto the stand (*fig. b*).

- If you plan to mount the AM antenna to a wall or other surface, secure the stand with screws (fig. c) before clipping the loop to the stand. Make sure the reception is clear.
- 4 Place the AM antenna on a flat surface and point in the direction giving the best reception.

Don't let it come into contact with metal objects and avoid placing near computers, television sets or other electrical appliances.¹


5 Connect the FM wire antenna in the same way as the AM loop antenna.

For best results, extend the FM antenna fully and fix to a wall or door frame. Don't drape loosely or leave coiled up.

Connecting external antennas


External AM antenna

Use 5 to 6 meters of vinyl-insulated wire and set up either indoors or outdoors. Leave the AM loop antenna connected.



External FM antenna

Use a PAL connector to hook up an external FM antenna.



Connecting to your TV

This system offers three types of video connections. If your TV has component video inputs, see *Connecting using the component video output* below.

1 Use the supplied yellow video cable to connect the VIDEO OUT jack to a video input on your TV.



2 Optionally: Use a stereo audio cable to connect the audio outs of your TV (or VCR) to the LINE IN jacks on the rear of this unit.


This will enable you to hear the TV (or VCR) sound through this system. See *Connecting auxiliary components* below for more on this.

Connecting using the component video output

If your TV has component video inputs, you can use these instead of the standard video output to connect this system to your TV.² This should give you the best quality picture from the three types of video output available.

- 1 The signal ground (ઋ) is designed to reduce noise that occurs when an antenna is connected. It is not an electrical safety ground.
- 2 The component video output is switchable between interlaced and progressive formats. See Video Output settings on page 44.

 Use a component video cable to connect the COMPONENT VIDEO OUT to a set of component inputs on your TV.



About progressive scan video

Compared to interlace video, progressive scan video effectively doubles the scanning rate of the picture, resulting in a very stable, flickerfree image. Progressive scan video is available only from the component video output.

Compatibility of this player with progressive-scan and high-definition TVs.

This player is compatible with progressive video Macro Vision System Copy Guard.¹

Connecting auxiliary components

This system has stereo analog inputs which you can use to connect external components, such as a VCR, MD player, or your TV.

• Connect the LINE IN jacks on the rear panel to an auxiliary playback component. Connect using RCA pin-plug stereo cables.

Connecting the power

After making sure that everything is connected properly, plug in the power cord to the AC inlet, and the other end to a mains power outlet.



Congratulations! You're done setting up.

POWER-CORD CAUTION

Handle the power cord by the plug. Do not pull out the plug by tugging the cord and never touch the power cord when your hands are wet as this could cause a short circuit or electric shock. Do not place the unit, a piece of furniture, etc., on the power cord, or pinch the cord. Never make a knot in the cord or tie it with other cords. The power cords should be routed such that they are not likely to be stepped on. A damaged power cord can cause a fire or give you an electrical shock. Check the power cord once in a while. When you find it damaged, ask your nearest PIONEER authorized service center or your dealer for a replacement.


Note

1 Consumers should note that not all high-definition television sets are fully compatible with this product and may cause artifacts to be displayed in the picture. In case of 525 progressive scan picture problems, it is recommended that the user switch the connection to the 'standard definition' output (Interlace). If there are questions regarding our TV set compatibility with this model, please contact our customer service center.

Chapter 3

Controls and displays

Front panel



1 Remote sensor

2 TIMER indicator

Lights when the timer has been set (page 40).

3 O STANDBY/ON

Switches the player on or into standby.

4 ENTER

Selects options or executes commands.

5 Tape cassette controls

ASES – Press for CD-to-tape synchro recording (page 35).

REC/STOP – Starts/stops recording on the tape deck (page 35).

6 X.BOOM button

Switches on the bass boost (page 39).

7 PHONES jack

Headphone jack.

8 Display

See Display below.

9 Tuning/playback controls / Volume dial / X.BOOM LED

The tuning/scan/skip buttons are used for tuning into stations, skipping or scanning tracks on discs or tapes. The playback control buttons are used for playing, pausing and stopping playback. The volume dial adjusts the volume level. The **X.BOOM** LED lights to show the current bass boost setting (page 39).

10 FUNCTION

Selects the source you want to listen to.

11 PLAY LIST buttons

Adds tracks to (during playback), or selects the playlist (while stopped) (page 29).

12 DVD OPEN/CLOSE

Opens / closes the disc tray.

13 PUSH OPEN

Pressing down on this side on the cassette door will open the tape deck.

14 Disc tray

15 MIC VOL and MIC input jacks

Controls the volume of the karaoke mics (**MAIN** and **SUB**) (page 38).

16 USB interface

Connect a USB device for playback (see *USB* playback on page 32).

Controls and displays

Display 2 3 4 SHELL IN STREET OF THE SHELL IN STREET OF THE SHELL IN SHEL

1 Speaker and playback indicators

The playback indicator (►) lights during playback, and the speaker indicators (EV7DVD/EV9DVD only) show which speakers are being used to output the current source. The illustrations below show some example displays.



5.1 channel surround sound



Stereo (2.1 channel) sound



2 channel sound



5.1 channel surround sound with the Front Surround or Extra Power mode active

(When headphones are connected, none of the speaker indicators are lit.)

2 Character display

3 Format indicators

DID PRO LOGIC II (EV7DVD/EV9DVD only) — Lights during Dolby Pro Logic II decoding.
DID DIGITAL — Lights during playback of a Dolby Digital signal.

DTS – Lights during playback of a DTS source.

4 *

Lights when the sleep timer is active.

5 ◀▶

Indicates the direction of tape playback.

6 Karaoke indicators

ECHO – Lights when the Karaoke **ECHO** effect is selected.

KEY – Lights when the Karaoke pitch control is selected.

KARAOKE (Vocal cancel) – Vocals in the backing track are partially eliminated using FQ.

L – Left channel only. Use for tracks that have a vocal recorded in the right channel.

R – Right channel only. Use for tracks that have a vocal recorded in the left channel.

L R – Use to put a single-channel vocal track into the center of the mix.

7 Timer indicators

WAKE-UP – Lights when the wake-up timer is set.

— Lights when the wake-up timer is set and flashes when it activates.

REC – Lights when the record timer is set and flashes when the timer starts recording.

8 Tuner indicators

MONO – Lights when FM mono reception is selected.

STEREO – Lights when a stereo FM broadcast is being received in auto stereo mode.

TUNED – Lights when a broadcast is being received.

9 B.CUT

Lights when the beat cut mode has been switched to **B.CUT 2** (for recording).

10 🕰

Lights during multi-angle scenes on a DVD.

11 Playback mode indicators

RDM – Lights during random playback.

RPT-1 – RPT lights during repeat play (RPT-1 lights during repeat one-track play).

PGM – Lights during program play.

Controls and displays

12 96 kHz

Lights when a 96 kHz source is detected (may not light if the source is copy-protected).

13 Cassette deck indicators

REC MODE (EV7DVD/EV9DVD only) – Lights during normal/ASES recording to indicate that some sound settings can't be adjusted.

ASES REC – Lights during ASES recording.

– Indicates the reverse mode.


14 Level meter

15 SFC

Lights when one of the Sound Field Control listening modes is selected.

Remote control

Illustration shows the EV7DVD/EV9DVD model



1 & STANDBY/ON

Switches the player on or into standby.

2 Input source function select

Selects the source you want to listen to.

3 Number buttons and SHIFT functions

The number buttons can be used for selecting tracks directly, the functions above the buttons are accessed by pressing **SHIFT** at the same time as the button.

PGM (**SHIFT**+**1**) – Use to program/play a program list (page 28).

RPT (**SHIFT**+**2**) – Selects a repeat play mode (page 27).

RDM (SHIFT+3) – Selects a random play mode (page 28).

 $\begin{array}{l} \textbf{ST.MEMORY} \; (\textbf{SHIFT} + \textbf{5}) - \text{Use for saving} \\ \text{and listening to station presets (page 37)}. \end{array}$

MONO (**SHIFT**+**6**) – Press to listen to a stereo FM broadcast in mono (page 20).

AUDIO (SHIFT+7) (EV7DVD/EV9DVD only) – Selects the audio channel or language (page 31).

SUBTITLE (**SHIFT**+**8**) (*EV7DVD/EV9DVD* only) – Selects a subtitle display (page 30).

ANGLE (SHIFT+9) (EV7DVD/EV9DVD only) – Changes the camera angle during DVD multi-angle scene playback (page 31).

TIMER (EV7DVD/EV9DVD: **SHIFT**+**CLEAR** / EV5DVD: **SHIFT**+**9**) – Use for setting and checking the clock (page 17) and the timers (page 40).

ZOOM (SHIFT+0) (EV7DVD/EV9DVD only) - Changes the zoom level (page 31).

CLEAR – Clears an entry.

ENTER – Selects menu options, etc.

4 HOME MENU

Press to display (or exit) the on-screen menu for Initial Settings, Play Mode functions, etc.

SYSTEM SETUP (SHIFT+HOME MENU)

Use to make various system and surround sound settings (page 48). Also used when automatically saving station presets when using the tuner (page 37).

5 ENTER, TUNE & cursor control buttons

Navigates on-screen displays and menus. **ENTER** selects an option or executes a command.

Controls and displays

6 SOUND MODE

Accesses settings in the Sound menu, such as the tone controls (page 39).

TEST TONE (SHIFT+SOUND MODE) (EV7DVD/EV9DVD only) – Press to output the test tone for speaker setup (page 21).

7 Sound Field / listening mode buttons

SFC – Selects sound modes or custom settings from the Sound Field Control (page 39).

SURROUND (EV7DVD/EV9DVD only) – Selects a surround listening mode (page 23).

FRT.SURR (EV7DVD/EV9DVD only) – Switches on the Front Surround mode (page 24).

EXT PWR (EV7DVD/EV9DVD only) – Switches on the Extra Power mode (page 24).

DISPLAY (EV5DVD only) – Switches between information displays (page 31).

8 Playback controls

- ► Starts/resumes playback.
- → and →I/→II Use for reverse slow motion playback, frame reverse and reverse scanning.
- ►► and II►/I► Use for forward slow motion playback, frame advance and forward scanning.
- ▶► Jumps to the next chapter or track.
- I Jumps to the beginning of the current chapter or track, then to previous chapters/tracks.
- – Pauses playback; press again to restart.
- Stops playback.
- 9 TV CONTROL¹ (EV7DVD/EV9DVD only)

ტ – Switches the TV on or into standby.

INPUT – Switches the TV input.

CHANNEL +/- – Selects channels.

VOLUME +/- – Adjusts the TV volume.

10 SHIFT

Press to access the functions/commands written in green on the remote.

11 X.BOOM

Switches the bass boost on or off (page 39).

12 PLAY LIST buttons

Adds tracks to (during playback), or selects the playlist (while stopped) (page 29).

13 KARAOKE controls

KARAOKE – Selects audio channels for karaoke (page 38).

ECHO – Changes the echo level on the karaoke mics (page 38).

#/b - Raises/lowers the pitch of the backing track (page 38).

14 MENU

Displays the DVD menu (for Video CD/ Super VCDs, DivX video and WMA/MP3/ MPEG-4 AAC/JPEG discs, the Disc Navigator screen appears).

TOP MENU (SHIFT+MENU)

Displays the top menu of a DVD disc.

15 RETURN

Press to return to a previous menu screen.

CH LEVEL (**SHIFT**+**RETURN**) (*EV7DVD*/ *EV9DVD only*) – Use to adjust the speaker level (page 21).

16 DVD controls (EV5DVD only)

AUDIO – Selects the audio channel or language (page 31).

SUBTITLE – Selects a subtitle display (page 30).

ANGLE – Changes the camera angle during DVD multi-angle scene playback (page 31).

ZOOM – Changes the zoom level (page 31).

17 DISPLAY (EV7DVD/EV9DVD only)

Switches between information displays (page 31).

18 MUTE

Mutes the volume (page 39).

19 VOLUME

Adjusts the volume level.

Note


1 Refer to Using the remote to control your TV on page 17 to use these controls with your TV.

Chapter 4 Getting started


Setting the clock

Setting the clock allows you to use the timer. 1

- 1 Press TIMER.
 - EV7DVD/EV9DVD:SHIFT+CLEAR:



FV5DVD: SHIFT+9:



- 2 If 'CLK ADJ?' isn't in the display, select it with ← or →, then press ENTER.
- 3 Use **↑**/**↓** to set the hour. Press ENTER.
- 4 Use ↑/↓ to set the minute then press ENTER to confirm.

Using the remote to control your TV

EV7DVD/EV9DVD model only

You can set up the supplied remote to control your TV using the **TV CONTROL** buttons.²

- 1 Switch on your TV.
- 2 Find the name of the manufacturer of your TV in the Preset Code List on page 60.

Next to each manufacturer is one or more three digit codes. These tell the remote what kind of TV you have.

If the name of the manufacturer of your TV does not appear in the table, you won't be able to set up this remote to control your TV.

3 Point the remote at your TV, hold down the CLEAR button, then enter the three digit code for your TV.

The remote transmits an on/off signal to the TV. If you've entered the correct code, your TV should switch off.

If your TV doesn't turn off, repeat the procedure using the next code in the list until your TV switches off successfully. Once set, you can then use the individual TV controls shown below.

| Button | What it does |
|-------------|---|
| Q | Switches your TV on or into standby. |
| CHANNEL +/- | Changes the TV channel. |
| VOLUME | Adjusts the volume. |
| INPUT | Switches the TV's input between the built in TV tuner and an external video source. |

Using the on-screen displays

For ease of use, this system makes extensive use of graphical on-screen displays (OSDs).

- 1 The default setting is 12-hour format. See Optional system settings on page 48 to change it.
- 2 The default setting is for a Pioneer TV.
 - Note that there are also cases where the codes listed for a manufacturer in the Preset Code List may not work for your TV.

Getting started

All the screens are navigated in basically the same way, using the cursor buttons (♠, ♣, ←, →) to change the highlighted item and pressing **ENTER** to select it.¹



Important

 Throughout this manual, 'Select' means use ↑/↓/←/→ to highlight an item onscreen, then press ENTER.

| Button | What it does |
|--------------|---|
| HOME MENU | Displays/exits the on-screen display |
| ← ↓↓→ | Changes the highlighted menu item |
| ENTER | Selects the highlighted menu item |
| RETURN | Returns to the main menu without saving changes |



Tip

 The button guide at the bottom of every OSD screen shows you which buttons you'll need to use for that screen.

Playing discs

The basic playback controls for DVD, CD, Video CD/Super VCD, DivX video and WMA/MP3/MPEG-4 AAC discs are covered here. Further functions are detailed in chapter 7.

- 1 If the player isn't already on, switch it on. If you're playing a disc with video, also turn on your TV and make sure that it is set to the correct video input.
- 2 Press DVD OPEN/CLOSE on the front panel to load a disc.

Load a disc with the label side facing up, using the disc tray guide to align the disc (if you're loading a double-sided DVD disc, load it with the side you want to play face down).



3 Press ► (play) to start playback.

If you're playing a DVD or Video CD/Super VCD, a menu may appear. See *DVD-Video disc* menus on page 19 and *Video CD/Super VCD PBC menus* on page 19 to navigate these.

If you loaded a disc containing JPEGs, a slideshow will start. See *Playing a JPEG slideshow* on page 25 for more on this.

- If a disc contains a mixture of DivX video and other media file types (MP3, for example), first select whether to play the DivX video files (DivX) or the other media file types (MP3 / WMA / MPEG-4 AAC / JPEG) from the on-screen display.
- 4 Adjust the volume.

Use the **VOLUME** +/- control.

Basic playback controls

The following table shows the basic controls on the remote for playing discs². You can find other playback features in the chapter 7.

Button What it does

- Starts/resumes normal playback.
 - If the display shows **RESUME** or **LAST MEM** playback starts from the resume or last memory point (see *Resume and Last Memory* below).
- Pauses/unpauses a disc.

- 1 The screen saver will appear after five minutes of inactivity.
- 2 You may find with some DVD discs that some playback controls don't work in certain parts of the disc.

Getting started

| Button | What it does |
|-----------------|--|
| • | Stops playback or cancels the resume function (if the display shows RESUME). |
| 44 | Press to start fast reverse scanning. |
| >> | Press to start fast forward scanning. |
| 44 | Skips to the start of the current track or chapter, then previous tracks/chapters. |
| ▶▶ | Skips to the next track or chapter. |
| Numbers | Use to enter a title/chapter/track number. Press ENTER to select. • If the disc is stopped, playback starts from the selected title (for DVD) or track (for CD/Video CD/Super VCD). • If the disc is playing, playback jumps to the start of the selected title (VR mode DVD-R/RW), chapter (DVD-Video) or track (CD/Video CD/Super VCD). |

Resume and Last Memory

When you stop playback of a disc, **RESUME** shows in the display indicating that you can resume playback from that point.

With DVDs and Video CD/Super VCDs, even if ejected, the play position is stored in memory. ¹ The next time you load the disc, the display shows **LAST MEM** and you can resume playback.

If you want to clear the resume point, press ■ (stop) while **RESUME** is displayed.

DVD-Video disc menus

Many DVD-Video discs contain menus from which you can select what you want to watch.

Sometimes DVD-Video menus are displayed automatically when you start playback; others only appear when you press **MENU** or **TOP MENU** (SHIFT+MENU).

| Button | What it does |
|--------------------------|---|
| TOP MENU (SHIFT+MENU) | Displays the 'top menu' of a DVD disc—this varies with the disc. |
| MENU | Displays a DVD disc menu—this varies with the disc and may be the same as the 'top menu'. |
| ← ↓↓→ | Moves the cursor around the screen. |
| ENTER | Selects the current menu option. |
| RETURN | Returns to the previously displayed menu screen. |
| Numbers | Highlights a numbered menu option (some discs only). Press ENTER to select. |

Video CD/Super VCD PBC menus

Some Video CD/Super VCDs have menus from which you can choose what you want to watch. These are PBC (Playback control) menus.

You can play a PBC Video CD/Super VCD without having to navigate the PBC menu by starting playback using a number button to select a track, rather than the ► (play) button.

| Button | What it does |
|-----------------|--|
| RETURN | Displays the PBC menu. |
| Numbers | Selects numbered menu options. Press ENTER to select. |
| 44 | Displays the previous menu page (if there is one). |
| >> | Displays the next menu page (if there is one). |

- 1 The Last Memory function may not work with some discs.
 - For DVD-Video discs (except VR mode DVD-R/RW), the player stores the play position of the last five discs.

Getting started

Listening to the radio

The tuner can receive both FM and AM broadcasts, and lets you memorize your favorite stations so you don't have to manually tune in every time you want to listen (see *More tuner features* on page 37 for more on this).

1 Press TUNER (FM/AM) to switch to the tuner, then press repeatedly to select the AM or FM band.

The display shows the band and frequency.

2 Tune to a frequency.

There are three tuning modes—manual, auto, and high-speed:

- Manual tuning: Press TUNE +/repeatedly to change the displayed frequency.
- Auto tuning: Press and hold TUNE +/until the frequency display starts to move,
 then release. The tuner will stop on the next
 station it finds. Repeat to keep searching.
- High-speed tuning: Press and hold TUNE
 +/- until the frequency display starts to
 move rapidly. Keep the button held down
 until you reach the frequency you want. If
 necessary, fine tune the frequency using
 the manual tuning method.

Improving FM stereo sound

If you're listening to an FM station in stereo but the reception is weak, you can improve the sound quality by switching to mono.

Press MONO (SHIFT+6) to choose 'FM MONO?' then press ENTER.

The **MONO** indicator lights when the tuner is in mono reception mode.

Select **FM AUTO?** above to switch back to autostereo mode (the **STEREO** indicator lights when receiving a stereo broadcast).

Listening to other sources

You can connect an external source for playback through this system's speakers. See *Connecting auxiliary components* on page 12 for more on this.

- To connect a USB device to the USB terminal, see *USB playback* on page 32.
- 1 Make sure that the external source (TV, MD player, etc.) is switched on.
- 2 Press LINE to select the source connected to the rear panel LINE input.
- If necessary, start playback of the source.

Dimming the display

You can choose one of two brightness settings for the front panel display.

- 1 Press SYSTEM SETUP (SHIFT+HOME MENU) and use ←/→ to choose DIMMER then press ENTER.
- 2 Use ←/→ to choose LIGHT or DARK then press ENTER to confirm and exit.

The **DARK** setting also switches off the front panel **X.BOOM** LED.


Setting up for surround sound

EV7DVD/EV9DVD model only

Home theater sound setup


Depending on the size and characteristics of your room, you can place your speakers in one of two ways using this system.¹

 Standard surround 5-spot setup – This is a standard multichannel surround sound speaker setup for optimal 5.1 channel home theater sound.




• Front surround 3-spot setup – This setup is ideal when rear surround speaker placement isn't possible or you want to avoid running long speaker cables in your listening area. Use this setup together with the Front Surround modes to take advantage of wall and ceiling reflections for a very realistic surround effect.

EV7DVD model speaker configuration:



EV9DVD model speaker configuration:



After placing your speakers, complete Setting the channel levels then refer to Speaker Distance on page 47 to complete your surround sound setup.

Setting the channel levels

Set the relative channel levels from your main listening position.²

- 1 Switch to the DVD/CD or USB input source.
- 2 Press TEST TONE (SHIFT+SOUND MODE).

The test tone is output in the following order (from the speakers active in the current listening mode):

- L Front left speaker
- C Center speaker
- R Front right speaker
- **SR** Surround right speaker
- **SL** Surround left speaker
- SW Subwoofer³

- 1 See About the listening modes on page 23 for more on using the different listening modes with each speaker setup.
- 2 Make sure headphones are unplugged.
- The channel balance can be adjusted (independently for each listening mode) while listening to any sound source you want: Press **CH LEVEL** (**SHIFT+RETURN**) then use ←/→ to select channels and ↑/↓ to adjust the level. Press **ENTER** when you're finished.
- 3 Since the subwoofer produces ultra-low frequencies its sound may seem quieter than it actually is.

Setting up for surround sound

3 Use the VOLUME +/- button to adjust the volume to an appropriate level.

You can also use the front panel volume dial.

4 Use the ↑/↓ buttons to adjust the speaker levels in turn.

You should hear the test tone at the same volume from each speaker when seated in the main listening position. The channel level range is \pm 10 dB.

5 When you're done, press TEST TONE to exit test tone setup.

Chapter 6 Home theater sound

EV7DVD/EV9DVD model only

About the listening modes

As explained in *Home theater sound setup* on page 21, there are two basic surround speaker setup options available. Of course you can select any of the listening modes regardless of how you place your speakers, but you will achieve the best surround effect by using the listening modes in conjunction with your speaker setup:

- Standard surround 5-spot setup Use the Standard (*Listening in surround sound* on page 23) surround listening modes with this setup.
- Front surround 3-spot setup See *Using Front Surround* on page 24 for the options available with this speaker setup.

Make sure you have completed *Setting the channel levels* on page 21.

Auto listening mode

The Auto listening mode is the simplest way to listen to any source as it was mastered: the output from the speakers mirrors the channels in the source material.



 Press SURROUND to select the AUTO listening mode.¹

Listening in surround sound

You can listen to stereo or multichannel sources in surround sound. Surround sound is generated from stereo sources using one of the Dolby Pro Logic decoding modes.



- 1 Switch to the DVD/CD or USB input source.
- 2 Press SURROUND repeatedly to select a listening mode.²

The choices that appear in the display will vary according to the type of source that's playing.

- AUTO Auto listening mode (see above)
- **DOLBY DIGITAL** / **DTS** Dolby Digital or DTS decoding (depending on the source). For a multichannel source, this will be the same as **AUTO**.
- DOLBY PL (Dolby Pro Logic) 4.1 channel surround sound for use with any twochannel source
- MOVIE (Dolby Pro Logic II Movie) Pro Logic II 5.1 channel surround sound, especially suited to movie sources (use with any two-channel source)
- MUSIC (Dolby Pro Logic II Music) Pro Logic II 5.1 channel surround sound, especially suited to music sources, for use with any two-channel source
- STEREO See Listening in stereo below


Note

11 If the source is Dolby Digital or DTS, the corresponding indicator lights in the front panel display.
2 When listening in **DOLBY DIGITAL/DTS** mode, two-channel material will automatically be played in surround sound using Dolby Pro Logic II decoding.

Using Front Surround

The Front Surround mode is effective when you are using the Front surround 3-spot speaker setup as described in *Home theater sound* setup on page 21.

 EV7DVD model – The surround speakers should be placed on top of the front speakers and oriented (about 60°) towards the walls (as a guide, line up the edge of the speaker stand base with the front edge of the speaker as shown below).



 EV9DVD model – The surround speakers should be placed beside the front speakers and oriented (about 60°) towards the walls.





 Press FRT.SURR to select the Front Surround mode.

Using the Extra Power mode

The Extra Power mode uses the Front surround 3-spot speaker setup as described above, but the surround speakers should be pointed in the same direction as the front speakers (towards the listening position).



Press EXT PWR to select the Extra Power mode.

Listening in stereo

You can listen to any source—stereo or multichannel—in stereo. When playing a multichannel source, all channels are downmixed to the front left/right speakers and the subwoofer.



 Press SURROUND repeatedly until STEREO shows in the display.

Listening with headphones

When headphones are connected, only the **STEREO** mode is available.¹

1 When you disconnect them it reverts to the previous mode.

Chapter 7 Disc playback features

A Important

- Many of the functions covered in this chapter apply to DVD discs, Video CDs/ Super VCDs, CDs, DivX video and WMA/ MP3/MPEG-4 AAC/JPEG discs, although the exact operation of some varies slightly with the kind of disc loaded.
- Some DVDs restrict the use of some functions (random or repeat, for example) in some or all parts of the disc. This is not a malfunction.
- When playing Video CD/Super VCDs, some
 of the functions are not available during
 PBC playback. If you want to use them,
 start the disc playing using a number
 button to select a track.

Scanning discs

You can fast-scan discs forward or backward at various different speeds.¹

• During playback, press ◀◀ or ▶► to start scanning.

Press repeatedly to increase the scanning speed (shown on-screen).

To resume playback, press ► (play).²

Playing in slow motion

You can play DVDs, Video CD/Super VCDs and DivX video at four different forward slow motion speeds. DVD discs can also be played in reverse slow motion.

- 1 During playback, press II (pause).
- 2 Press and hold ◀I/◀II or II►/I► until slow motion playback starts.

Press repeatedly to change the slow motion speed (shown on-screen).

To resume playback, press ➤ (play).²

Frame advance/frame reverse

With DVD discs, you can move forward/back frame-by-frame. With Video CD/Super VCDs and DivX video you can only use frame advance.

- 1 During playback, press II (pause).
- 2 Press **◄**I/**◄**II or II►/I► to reverse or advance a frame at a time.
 - To resume playback, press ➤ (play).²

Playing a JPEG slideshow

After loading a disc containing JPEG pictures, press ► to start a slideshow from the first folder/picture on the disc.³ The player displays the pictures in each folder in alphabetical order.

If the disc contains WMA/MP3/MPEG-4
 AAC files, playback of the slideshow and
 audio files repeats. During audio playback,
 you can still use the skip (I◄◄/▶►I), scan
 (◄◄/▶►) and pause (II) functions.

Pictures are automatically adjusted so that they fill as much of the screen as possible.

Note

1 Only one speed is available for DivX video discs.

- 2 Depending on the disc, normal playback may automatically resume when a new chapter is reached on a DVD disc.
- With Video CD/Super VCDs in PBC mode or a WMA/MP3/MPEG-4 AAC track, playback automatically resumes at the end or beginning of the track.
- 3 The time it takes for the player to load a file increases with large file sizes.
 - Discs can contain up to 299 folders and up to 648 folders and files combined.

While the slideshow is running:

| Button | What it does |
|-----------------|---|
| II | Pauses the slideshow (or audio); press again to restart. |
| 44 | Jumps to the previous picture (or audio file with audio playback). |
| >> | Jumps to the next picture (or audio file with audio playback). |
| ←/→/↑/↓ | Pauses the slideshow and rotates/flips the displayed picture (Press ► (play) to restart slideshow). |
| ZOOM | Pauses the slideshow and zooms the picture. Press again to toggle between 1x, 2x and 4x zoom (Press ► (play) to restart slideshow). |
| MENU | Displays the Disc Navigator screen (see below). |


Browsing DVD or Video CD/ Super VCD discs with the Disc Navigator

Use the Disc Navigator to browse through the contents of a DVD or Video CD/Super VCD disc to find the part you want to play.

1 During playback, press HOME MENU and select 'Disc Navigator' from the onscreen menu.



2 Select a view option.




The options available depend on the kind of disc loaded and whether the disc is playing or not, but include:

- Title Titles from a DVD-Video disc.
- Chapter Chapters from the current title of a DVD-Video disc.
- Track Tracks from a Video CD/Super VCD disc.
- Time Thumbnails from a Video CD/Super VCD disc at 10 minute intervals.
- Original: Title Original titles from a VR mode DVD-R/RW disc.
- Playlist: Title Playlist titles from a VR mode DVD-R/RW disc.
- Original: Time Thumbnails from the Original content at 10 minute intervals.
- **Playlist: Time** Thumbnails from the Playlist at 10 minute intervals.

The screen shows up to six moving thumbnail images displayed one after another. To display the previous/next six thumbnails, press ◄◄/ ►►

3 Select the thumbnail image for what you want to play.



You can use either the $\uparrow/\downarrow/\leftarrow/\rightarrow$ and **ENTER** to select a thumbnail, or the number buttons.

To select using the number buttons, enter a two-digit number then press **ENTER**.

Browsing WMA, MP3, MPEG-4 AAC, DivX video and JPEG files with the Disc Navigator

Use the Disc Navigator to find a particular file or folder by filename.

1 Press HOME MENU and select 'Disc Navigator' from the on-screen menu.



2 Use $\uparrow/\downarrow/\leftarrow/\Rightarrow$ and ENTER to navigate. Use \uparrow/\downarrow to move up / down the folder/file list.

Use ← to return to the parent folder. 1

Use **ENTER** or → to open a highlighted folder.

 When a JPEG file is highlighted, a thumbnail image is displayed on the right.



3 To play the highlighted track or DivX video file or display the highlighted JPEG file, press ENTER.

- When a WMA/MP3/MPEG-4 AAC or DivX video file is selected, playback begins from that file, and continues until the end of the folder.
- When a JPEG file is selected, a slideshow begins, starting with that file, and continues to the end of the folder.



- You can also play a JPEG slideshow while listening to WMA/MP3/MPEG-4 AAC playback. Simply select the audio file you want to listen to followed by the JPEG from which you want the slideshow to start. Playback of both the slideshow and the audio files repeats. Playback controls are effective for the JPEG slideshow only.
- To play the contents of the whole disc rather than just the current folder, exit the Disc Navigator and start playback using the ► (play) button.

Looping a section of a disc

The A-B Repeat function allows you to specify two points (A and B) within a track (CD, Video CD/Super Video CD) or title (DVD) that form a loop which is played over and over.

- 1 During playback, press HOME MENU and select 'Play Mode'.
- 2 Select 'A-B Repeat'.
- 3 Press ENTER on 'A(Start Point)' to set the loop start point.
- 4 Press ENTER on 'B(End Point)' to set the loop end point.

After pressing **ENTER**, playback jumps back to the start point and plays the loop.

5 To resume normal playback, select 'Off'.

Using repeat play

In addition to various repeat play options, it's also possible to use repeat play together with program play (see *Creating a program list* on page 28).

1 During playback, press HOME MENU and select 'Play Mode'.



2 Select 'Repeat' then select a repeat play option. 1

If program play is active, select **Program Repeat** to repeat the program list, or **Repeat Off** to cancel.

- For DVD discs, select Title Repeat or Chapter Repeat.
- For CDs and Video CD/Super VCDs, select Disc Repeat or Track Repeat.
- For DivX video discs, select Title Repeat (or Repeat Off).



 You can also use the RPT (SHIFT+2) button on the remote to select a repeat play option. The repeat modes available are the same as those from the Play Mode menu.

Using random play

Use this function to play titles or chapters (DVD-Video) or tracks (CD and Video CD/Super VCD) in a random order.²

- 1 During playback, press HOME MENU and select 'Play Mode'.
- 2 Select 'Random' then select an option.
 - For DVD discs, select **Random Title** or **Random Chapter**.
 - For CDs and Video CD/Super VCDs, select
 On or Off to switch random play on or off.

<equation-block> Тір

Use the following controls during random play:

| Button | What it does |
|-----------------|---|
| >> | Selects a new track/title/chapter at random. |
| 44 | Returns to the beginning of the current track/title/chapter; further presses select another random track/title/chapter. |

- You can also use the RDM (SHIFT+3) button on the remote to select a random play mode. The random modes available are the same as when choosing from the Play Mode menu. Press ENTER to start random play.
- Random play remains in effect until you select Random Off from the random play menu options.

Creating a program list

This feature lets you program the play order of titles/chapters/tracks on a disc.³

Using the OSD

- 1 During playback, press HOME MENU and select 'Play Mode'.
- 2 Select 'Program' then select 'Create/Edit' from the list of program options.
- 3 Use ↑/↓/←/→ and ENTER to select a title, chapter or track for the current step in the program list.

For a DVD disc, you can add a title or a chapter.

- You can't use repeat play with WMA/MP3/MPEG-4 AAC discs.
- 2 You can set the random play option when a disc is playing or stopped. However, you can't use random play together with program play.
- You can't use random play with VR format DVD-R/RW discs, WMA/MP3/MPEG-4 AAC discs, DivX video discs, or while a DVD disc menu is being displayed.
- 3 You can't use Program play with VR format DVD-R/RW discs, WMA/MP3/MPEG-4 AAC discs, DivX video discs, or while a DVD disc menu is being displayed.

• For a CD or Video CD/Super VCD, select a track to add to the program list.

After pressing **ENTER** to select the title/ chapter/track, the step number automatically moves down one.

4 Repeat step 3 to build up a program list.

A program list can contain up to 24 steps.

- You can insert steps by just highlighting the position where you want the new step to appear and entering a title/chapter/track number.
- To delete a step, highlight it and press **CLEAR**.

5 To play the program list, press ▶ (play).

Program play remains active until you turn off program play (see below), erase the program list (see below), eject the disc or switch off.



• Use the following controls during program play:

| Button | What it does |
|--------------|---|
| HOME MENU | Save the program list and exit without starting playback. |
| ▶ ▶ | Skip to the next step in the program list. |

Other functions available from the program menu

There are a number of other options in the program menu in addition to Create/Edit.

- Playback Start Starts playback of a saved program list
- Playback Stop Turns off program play, but does not erase the program list
- **Program Delete** Erases the program list and turns off program play

Using the front panel display

Even though the OSD is available for CDs, the front panel display provides information to make a program list easily. If a disc is playing, stop it first.

1 Press PGM (SHIFT+1).

You're prompted to enter a track for the first step in the program list.

2 Use the number buttons to select a track, then press ENTER.

If you make a mistake, press **CLEAR** to delete the last (most recently) programmed track.

- **3** Repeat step 2 to build up a program list. A program list can contain up to 24 steps.
- 4 To play the program list, press ▶ (play).
 - Program play remains active until you press (stop), clear the playlist (see tip above), eject the disc or switch off the player.

Using Playlists

With this feature, you can make up to three playlists of 30 files each for discs containing WMA, MP3, MPEG-4 AAC and JPEG files. Since this unit will remember all playlists for the last ten discs you have loaded, this is useful for if you have a large number of files that you want to organize quickly and easily. 1

Programming playlists

- 1 With the disc stopped, press HOME MENU and select 'Disc Navigator' from the on-screen menu.
- 2 Select the file you want to add to the playlist.

See Browsing WMA, MP3, MPEG-4 AAC, DivX video and JPEG files with the Disc Navigator on page 27 if you don't know how to do this.

Note

1 The disc must be loaded for the files in your playlist to play back.

3 Press PLAY LIST 1, 2 or 3.

The file is added to the playlist you select.

4 Repeat steps 2 and 3 until you're done.



 To add files without the on-screen display, simply press PLAY LIST 1, 2 or 3 during normal playback of the file you want (except when a JPEG slideshow is playing at the same time as audio).

Listening to playlists

With playback stopped, press PLAY LIST 1, 2 or 3.

During playback, **PGM** lights in the front panel display.

- If no playlist has been programmed, NO LIST shows in the front panel display.
- If the playlist contains both JPEG and audio files, playback of the slideshow and audio files starts.

Clearing files from a playlist

- 1 Start playback of your playlist.
- 2 Press HOME MENU and select 'Disc Navigator'.
- 3 From the 'Disc Navigator' screen, select the file you want to remove from the playlist and press CLEAR.

Searching a disc

You can search DVD discs by title or chapter number, or by time; CDs and Video CD/Super VCDs by track number or time; DivX video discs by time.

1 Press HOME MENU and select 'Play Mode'.

2 Select 'Search Mode'.

The search options that appear depend on the kind of disc loaded.

3 Select a search mode.

 The disc must be playing in order to use time search.

4 Use the number buttons to enter a title, chapter or track number, or a time.

- For a time search, enter the number of minutes and seconds into the currently playing title (DVD/ DivX video) or track (CD/ Video CD/Super VCD) you want playback to resume from. For example, press 4, 5, 0, 0 to have playback start from 45 minutes into the disc. For 1 hour, 20 minutes and 30 seconds, press 8, 0, 3, 0.
- 5 Press ENTER to start playback.

Switching subtitles

Some DVD discs and DivX video discs have subtitles in one or more languages; the disc box will usually tell you which subtitle languages are available. You can switch subtitle language during playback.¹

• Press SUBTITLE repeatedly to select a subtitle option.

- EV7DVD/EV9DVD: SHIFT+8
- To set subtitle preferences, see *Language* settings on page 44.
- See *Displaying DivX subtitle files* on page 51 for more on DivX subtitles.

Note

1 Some discs only allow you to change subtitle language from the disc menu. Press **TOP MENU (SHIFT+MENU)** or **MENU** to access.

Switching language / audio channels

When playing discs recorded with dialog in two or more languages, or with dual-mono audio 1 you can switch these during playback. 2

- Press AUDIO repeatedly to select an audio language option.
 - EV7DVD/EV9DVD: SHIFT+7
 - To set audio language preferences, see Language settings on page 44.

Zooming the screen

Using the zoom feature you can magnify a part of the screen by a factor of 2 or 4, while watching a DVD, DivX video title or Video CD/Super VCD or playing a JPEG disc.

- 1 During playback, use the ZOOM button to select the zoom factor (Normal, 2x or 4x).
 - EV7DVD/EV9DVD: SHIFT+0
- 2 Use $\uparrow/\downarrow/\leftarrow/\Rightarrow$ to change the zoomed area.

You can change the zoom factor and the zoomed area freely during playback.³

Switching camera angles

Some DVD discs feature scenes shot from two or more angles—check the disc box for details.

When a multi-angle scene is playing, a playing, a playing icon appears on screen (this can be switched off if you prefer—see *Display settings* on page 45).

- During playback (or when paused), press ANGLE to switch angle.
 - EV7DVD/EV9DVD: SHIFT+9

Displaying disc information

Various track, chapter and title information can be displayed on-screen during playback.

 To show/switch/hide the information displayed, press DISPLAY repeatedly.

Limited disc information also appears in the front panel display. Press **DISPLAY** to change the displayed information.



- 1 Some Super VCDs have two soundtracks. With these discs you can switch between the two soundtracks as well as individual channels in each.
- 2 Some discs only allow you to change audio language from the disc menu. Press **TOP MENU** (**SHIFT+MENU**) or **MENU** to access.
- 3 Since DVD, Video CD/Super VCD, DivX video title and JPEG pictures have a fixed resolution, picture quality will deteriorate, especially at 4x zoom. This is not a malfunction.
 - If the navigation square at the top of the screen disappears, press ZOOM (EV7DVD/EV9DVD: SHIFT+0) again to display it.

Chapter 8 USB playback


Using the USB interface

It is possible to listen to two-channel audio¹ and watch JPEG files using the USB interface on the front of this unit. Connect a USB mass storage device² as shown below.

1 With the player switched on, press USB. Make sure your TV is on and set to the correct video input.

2 Connect your USB device.

The USB terminal is located on the front panel.



Press ► (play) to start playback.

If your USB device contains JPEGs, a slideshow will start. See Playing a JPEG slideshow on page 33 for more on this.

 Make sure **USB** is showing in the front panel display (or the system is in standby) when disconnecting.

Important

If a USB ERR message lights in the display, it may mean that the power requirements of the USB device are too high for this player, or that the device is incompatible. Try the following:

- · Switch the player off, then on again.
- Reconnecting the USB device with the player switched off.
- Selecting to another input source (like DVD/CD), then back to USB.
- Using a dedicated AC adapter (supplied) with the device) for USB power.

If this doesn't remedy the problem, it is likely your USB device is incompatible.

Basic playback controls

The following table shows the basic controls on the remote for USB playback.

| Button | What it does |
|-----------------|--|
| > | Starts normal playback. |
| Ш | Pauses/unpauses playback. |
| | Stops playback. |
| 44 | Press to start fast reverse scanning. |
| >> | Press to start fast forward scanning. |
| 44 | Skips to the start of the current file, then previous files. |
| >> | Skips to the next file. |

Note

This includes playback of WMA/MP3/MPEG-4 AAC files (except files with copy-protection or restricted playback). It is not possible to play DivX files through the USB terminal.

- 2 Compatible USB devices include external magnetic hard drives, portable flash memory (particularly keydrives) and digital audio players (MP3 players) of format FAT16/32. It is not possible to connect this unit to a personal computer for USB playback.
- · Pioneer cannot guarantee compatibility (operation and/or bus power) with all USB mass storage devices and assumes no responsibility for any loss of data that may occur when connected to this unit.
 - · With large amounts of data, it may take longer for the system to read the contents of a USB device.

USB playback

Scanning files

You can fast-scan forward or backward at various different speeds.

During playback, press ◄◄ or ▶►.

Press repeatedly to increase the scanning speed (shown on-screen).

To resume playback, press ➤ (play).¹

Playing a JPEG slideshow

Press ► to start a slideshow from the first folder/picture. The pictures in each folder are displayed in order.

If the device contains WMA/MP3/MPEG-4
 AAC files, playback of the slideshow and
 audio files repeats. During audio playback,
 you can still use the skip (I◄◄/►►I), scan
 (◄◄/►►) and pause (II) functions.

Pictures are automatically adjusted so that they fill as much of the screen as possible. While the slideshow is running:

| Button | What it does |
|-----------------|--|
| II | Pauses the slideshow (or audio); press again to restart. |
| 44 | Jumps to the previous picture (or audio file with audio playback). |
| >> | Jumps to the next picture (or audio file with audio playback). |
| ←/→/1/↓ | Pauses the slideshow and rotates/flips the current picture (Press ► to restart slideshow). |
| ZOOM | Pauses the slideshow and zooms the picture. Press again to toggle between 1x, 2x and 4x zoom (Press ► to restart slideshow). |

| Button | What it does |
|--------|--|
| MENU | Displays the Navigator screen (see below). |

Browsing files with the Navigator

Use the Navigator to find WMA, MP3, MPEG-4 AAC and JPEG files or folders by name.³

1 Press MENU then use **↑**/**↓**/**←**/**→** and ENTER to navigate.

Use **↑**/**↓** to move up/down the folder/file list.

Use to return to the parent folder.4

Use **ENTER** or → to open a highlighted folder.

 When a JPEG file is highlighted, a thumbnail image is displayed on the right.

2 To play the highlighted track or display the highlighted JPEG file, press ENTER.

- When a WMA/MP3/MPEG-4 AAC file is selected, playback begins from that file, and continues until the end of the folder.
- When a JPEG file is selected, a slideshow begins, starting with that file, and continues to the end of the folder.



- Tip
- You can also play a JPEG slideshow while listening to WMA/MP3/MPEG-4 AAC playback. Simply select the audio file you want to listen to followed by the JPEG from which you want the slideshow to start. Playback of both the slideshow and the audio files repeats. Playback controls are effective for the JPEG slideshow only.
- To play all of the contents, rather than just the current folder, exit the Navigator and start playback using the ► (play) button.

Note

1 With WMA/MP3/MPEG-4 AAC tracks, playback automatically resumes at the end or beginning of the track.

- 2 The time it takes for the player to load a file increases with large file sizes.
 - USB devices can contain up to 299 folders and up to 648 folders and files combined.
- 3 Filenames may be displayed incorrectly with some digital audio players.
- 4 You can also do this by going to the '..' folder at the top, then pressing **ENTER**.

Chapter 9 Using the tape deck

Playing cassette tapes

This unit has a tape deck that can be used for both recording and playback. In addition, it features automatic music search (AMS) and auto-reverse functions¹. See Making tape recordings below for more features.

- Push down on the cassette door where indicated to open it and insert a tape.
- 2 Close the cassette door.
- Press SYSTEM SETUP (SHIFT+HOME MENU) and use ←/→ to choose REVERSE then press ENTER.
- Use **↑**/**↓** to choose a reverse mode then press ENTER to confirm.

 - REVERSE (→) Auto-reverse playback: stops after finishing playback in the 'reverse' (◄) direction
 - ENDLESS () Continuous playback (up to 8 complete plays)
- Press TAPE to start playback.

You can also press ► (remote) or ►/II (front panel) to start playback when TAPE is selected. The side of the tape you'll hear is whichever is face up when you load it. This is the 'forward' (►) direction, while the other side is 'reverse' (◄). The direction indicator is shown in the

Basic playback controls

Button What it does

The following table shows the basic controls on the remote for playing discs.

| TAPE | Starts/resumes normal playback. Each |
|------|--|
| (▶) | time you press either button during |
| | playback, the other side of the tape |
| | starts playing. Pressing TAPE (►) |
| | when the tape is stopped starts |

playback on the side it was playing previously.

Pauses playback.

Ш

Stops playback. Also resets the tape counter to 0000 if pressed when the tape is already stopped.

Press to fast-rewind a tape.

Press to fast-forward a tape.

Searches for the previous / next blank

space between tracks on the side currently playing (in other words, to the start of the current / next track), then resumes playback.

> By pressing more than once, the tape will skip several tracks at once (up to a maximum of 15). For example, press ▶► twice to skip forward two tracks.

a. Track search is unlikely to work reliably if:

- the space between tracks is less than about 4 seconds.
- the recording is noisy so the spaces are not recognized.
- the recording contains frequent silences, such as a language study tape.
- the recording contains sections of very quiet material, such as some classical music recordings.

Note

display.

The auto-reverse feature lets you play or record a tape without physically taking it out and turning it over.

Using the tape deck

Making tape recordings

You can make tape recordings from the radio, CDs, or from an external component connected to the auxiliary inputs. ¹ If you're recording from CD it's convenient to use the ASES mode—see *Automatically recording CDs (ASES)* below.

Unlike some tape decks, there's no need to set recording levels; the deck sets the level automatically. When recording, the volume has no effect on the recording. This means that you can record something with the volume turned right down if you want.

1 Press TAPE then load a cassette into the tape deck.

In order to follow these instructions more easily, load the cassette² with side A facing up, then use the front panel controls.

2 Check the recording direction.

If you start recording in the ▶ direction, both sides of the tape can be recorded (unless the erase protect tab for side B is missing). If you switch sides and start recording in the ◀ direction, then recording will start from side B and stop when the end of the tape is reached. If you need to change the direction, press ▶/▮ (▶) twice, then ■ (stop).

3 Set the reverse mode (see above).

- \rightleftharpoons (record one side only)
- — or
 — (record both sides if recording starts in the ► (forward) direction, or one side if recording starts in the ◄ (reverse) direction)

4 Select the source you want to record.

For example, press **TUNER** (**FM/AM**) to record from the radio. If you've selected a CD, make sure that it's stopped. You can't record while **TAPE** is selected.

5 Prepare the source for recording.

For example, tune in the radio station.

6 Press REC/STOP (front panel only).

The **REC** indicator lights in the display and the deck starts recording.

- 7 Start the source playing (if necessary).
- 8 When you're ready to stop recording, press REC/STOP again.

Automatically recording CDs (ASES)

Auto Synchro Editing System (ASES for short) makes recording CDs³ automatic. It also makes sure that a CD track isn't spread over two sides of a tape.

If the tape runs out midway through a CD track, the same track is automatically recorded from the beginning again on the other side.⁴

1 Prepare the tape deck for recording. Recording starts in the ► (forward) direction, so take care which way you load the tape.

- 2 Load the CD you want to record.
- 3 Press DVD/CD, then press (stop).

The CD should now be selected, but not playing.

- 1 Once recording has started, you can't switch to another component until recording has stopped. So, for example, you can't switch over to the tuner while you're recording a CD.
- EV7DVD/EV9DVD model only During recording, all multichannel sources are downmixed to two channels. The Recording Mode switches on automatically to prevent any changes to the sound settings during tape recording. When the Recording mode is on, most sound features cannot be used. The display will briefly blink RMODE ON if you try and use a prohibited function.

 2 Before recording, check that the cassette erase-protect tabs have not been broken, and that the tape is Type I (normal position). You can't record on Type II (high/CrO2) or IV (metal) tapes using this deck.
- If you're recording from the start of a tape, it's a good idea to wind the tape on a little so that you don't accidently start recording over the leader tape. You can either do this by hand, or load the tape into the deck and play the tape for 5 to 6 seconds. 3 You can't make ASES tape recordings of Video CD/Super VCDs or DVD-Video discs.
- 4 ASES may not work correctly if the first side of the tape finishes at the same time as a track ends. If this happens, stop the recording then resume on the other side without ASES.

Using the tape deck

If you want to record the tracks in a different order, or record only one track, use the program play feature—see page 28 for how to make a program list. Make sure playback is stopped, then press **PGM** (**SHIFT+1**) before going to the next step.

4 Press ASES (front panel) to start recording.

The **ASES REC** indicator lights, followed by a 4 second pause while the tape winds past the leader, then recording starts.

Recording finishes automatically when the end of the disc is reached, or the tape ends (whichever comes first).

5 If you want to stop recording before the end of the CD, press ■ (stop).

🔐 Tip

 If you find that you're getting noisy recordings from an AM radio station, see Optional system settings on page 48 to change the beat cut mode.

Chapter 10 More tuner features

Memorizing stations

You can save up to 30 station presets so that you always have easy access to your favorite stations without having to tune in manually each time.

Manually saving station presets

- 1 Tune to an AM or FM radio station.
- For the FM band, select mono or auto-stereo reception as necessary. This setting is saved along with the preset.
- 2 Press ST.MEMORY (SHIFT+5), use ↑/↓ to select the station preset you want then press ENTER.

Automatically saving station presets

1 Press SYSTEM SETUP (SHIFT+HOME MENU), use ←/→ to choose 'A. PRESET' then press ENTER.

Auto tuning starts in the FM band, stopping when a strong signal is received.

2 When auto tuning stops at a station, press ENTER to save the station as a preset, or press ↑/↓ to continue without saving.

Auto tuning resumes. After the FM band is finished, auto tuning continues in the AM band. Press ■ (stop) anytime to exit.

Auto tuning stops automatically after the AM band is finished, or after the limit of 30 presets has been reached. When this happens, the tuner automatically switches to preset **ST-1**.

Listening to station presets

- 1 Press TUNER (FM/AM) repeatedly to select the station preset mode. The display shows ST.
- 2 Use ←/→ to select a station preset.
 - You can also use the number buttons and ENTER to do this.

Chapter 11 Singing karaoke

Singing karaoke

Using the karaoke features you can plug in a microphone and mix the sound of your own voice with a backing track. The backing track can be anything you like, from a song on the radio, to a dedicated DVD karaoke disc. Adjust the microphone level relative to the backing track.



1 Set the MIC VOL knob (front panel) to minimum.

2 Plug in the microphone(s).

If you're only using one mic, plug it into the **MIC (MAIN)** jack. The **MIC (SUB)** jack can be used only if **MIC (MAIN)** is also connected.

• If the microphone has an on/off switch, make sure it's on.

3 Load a karaoke backing disc or tape.

You can also use the radio or a component connected to the auxiliary inputs as source material for a backing track.

4 To change the mix (CD or Video CD/Super VCD only), press KARAOKE.

Press to switch between these options:²

• KARAOKE (Vocal cancel) – Backing track vocals are partially eliminated using EQ.

- L CH Left channel only. Use for tracks that have a vocal recorded in the right channel.
- R CH Right channel only. Use for tracks that have a vocal recorded in the left channel.
- L+R CH Use to put a single-channel vocal track into the center of the mix.
- OFF Switches the Karaoke mode off.
- 5 Play the backing track.

6 Adjust the MIC VOL knob.

To avoid unpleasant feedback, make sure you don't point the microphone(s) at the speakers.³

7 Sing!

Changing the vocal mix

Adding some effects to the microphone mix can sometimes improve the overall sound. You can choose between three echo levels.

To add effects to the microphone mix, press ECHO.

Pressing repeatedly switches between echo levels 1 to 3 and off.

Changing the backing track

You may want to lower or raise the pitch of the backing track to match your vocal range.⁴

• Press **KEY CONTROL** # (**SHIFT** + **KARAOKE**) or **b** (**SHIFT** + **ECHO**) to raise or lower the pitch of the backing track.

- 1 EV7DVD/EV9DVD model only These features are only possible when a microphone is connected. Also note that during DVD playback, using the karaoke features (including connecting a mic) automatically switches to **STEREO** playback and downmixes multichannel sources to two channels.
- 2 The current setting is first shown in the display.
- 3 Depending on the microphone level, the sound of the disc may distort. If this happens, turn down the volume.
- 4 Only available when the **DVD/CD** or **USB** input source is selected (however, with DTS signals there is no effect).

Chapter 12

Adjusting the sound

Using the Sound menu

There are several optional sound settings you can make from the sound menu.

1 Press SOUND MODE.

2 Use ←/→ to choose the setting you want to adjust.

The current setting is shown for each option (in the order shown in step 3, with the defaults in **bold**) as you cycle through the display.

3 Use **↑**/**↓** to adjust.

Make adjustments to the following settings:

| Setting | What it does | Option(s) |
|-----------------------|---------------------------------|-----------|
| Bass | Adjusts the amount of bass. | -4 to +4 |
| Treble | Adjusts the amount of treble. | -4 to +4 |
| Stereo | Makes the stereo spread | OFF |
| Wide (EV5DVD only) | appear wider than it really is. | ON |

4 Repeat steps 2 and 3 for other settings.

5 When you're done, press ENTER to leave the Sound menu.



 You can store your current bass, treble and stereo-wide settings as a preset. Simply hold ENTER for three seconds, then press ENTER again to confirm when USER shows in the display. You can now select this preset from the SFC menu (see Using the Sound Field Control below).

Using the Sound Field Control

Depending on the source you're listening to, you may want to use the Sound Field Control to match the source you're listening to. 1

• Press SFC repeatedly to select a mode.

The options are as follows:

- **STANDARD** Selects the default bass/ treble/stereo wide settings.
- **CRISPY** Emphasizes bright sounds.
- **SPICY** Sharpens the sound image (good for compressed audio such as MP3).
- POWER Good for music with lots of bass.
- **HEAVY** Good for rock music.
- **USER** See *Tip* above.
- **SFC OFF** (**SFC** indicator disappears)

Boosting the bass level

If you want to bring up the low end for certain kinds of music or sound sources, you can use the bass boost to do so.

- Press X.BOOM repeatedly to select a mode. The options are as follows (the X.BOOM LED lights as indicated in parantheses):
 - **X.BOOM M** Good for music with lots of bass (blue).
 - **X.BOOM MV** Boosts low frequency (bass) sounds in movies (orange).
 - OFF Switches the bass boost off.

Muting the sound

Press MUTE to switch off the volume.

To switch the sound back on, adjust the volume or press **MUTE** again.

Ø Note

1 If you have adjusted sound parameters for separate SFC modes (from the sound menu), these are applied as well.

Chapter 13 Using the timer

Important

- The clock must be set for the timers to work properly (see *Setting the clock* on page 17).
- Where the TIMER button is mentioned below, press SHIFT+CLEAR (EV7DVD/ EV9DVD) or SHIFT+9 (EV5DVD), according to your model.

Setting the wake-up timer

Use the wake-up timer to set the system to switch on at any time and start playing whatever source you want. ¹

- 1 Select the source you want played. For example, press TUNER (FM/AM) to select the radio as your source.
- **2 Prepare the source and set the volume.** For example, tune in the radio station you want to wake up to. Adjust the volume as necessary.
- 3 Press TIMER twice, use ←/⇒ to select WAKE-UP then press ENTER.
- 4 Use ←/→ to select EDIT then press ENTER.
- 5 Set the switch-on time.

Use ↑/↓ to set the hour, then press ENTER. Set the minute in the same way, pressing ENTER when you're done.

6 Set the switch-off time.

Set as above, pressing **ENTER** when done. The **WAKE-UP** indicator lights, and the switch-on, switch-off times, the function (**DVD/CD**, etc.) and volume are confirmed in the display.

7 Switch the system into standby mode.

The wake-up timer will not work if the system is left on!

 You can check the timer settings in standby by pressing TIMER twice.

Turning the wake-up timer on/off

If you have already set the wake-up timer, you can switch it on/off by selecting **TIME ON** or **TIME OFF** in step 4 above (press **ENTER**).

Setting the sleep timer

The sleep timer switches off the system after a specified time so you can fall asleep without worrying about it.²

- 1 Press TIMER twice, use ←/⇒ to select SLEEP then press ENTER.
- 2 Use \uparrow/\downarrow to select a switch-off time then press ENTER.

Choose between the following options:

- AUTO Switches off automatically after the currently playing CD or Video CD has finished.³
- SLEEP 90 Switches off after 90 minutes
- SLEEP 60 Switches off after an hour
- SLEEP 30 Switches off after 30 minutes
- OFF Cancels the sleep timer

3 To check how much time is left, repeat step 1.

The remaining time is displayed momentarily.

- You cannot have the wake-up timer and the record timer set at the same time.
- 2 If you set the sleep timer while either the wake-up or recording timer is active, the earlier switch off time takes priority.
- The system will switch into standby if you change the input function during AUTO sleep mode.
- 3 AUTO will not work with DVD/CDs in repeat play, cassette tapes, or Video CD/Super VCDs during PBC playback.

Using the timer

Setting the record timer

You can set the timer to record from the **LINE** source, or something off the radio. For example, you might want to record a program that is broadcast while you're at work.¹

1 Set up the tape deck.

Load a cassette tape, wind on past the leader tape and set the reverse mode (see *Making tape recordings* on page 35 for more on this).

- **2** Select the source you want to record. Press **TUNER** (**FM/AM**) or **LINE** and prepare the source.²
- 3 Press TIMER twice, use ←/→ to select 'REC?' then press ENTER.
- 4 Use ←/→ to select EDIT then press ENTER.
- 5 Set the switch-on time.

Use ↑/↓ to set the hour, then press **ENTER**. Set the minute in the same way, pressing **ENTER** when you're done.

6 Set the switch-off time.

Set as above, pressing **ENTER** when done. The **REC** indicator lights, then the switch-on, switch-off times and the function (or frequency, if you selected the tuner) are confirmed in the display.

7 Switch the system into standby mode.

The record timer will not work if the system is left on!

Turning the record timer on/off

If you have already set the record timer, you can switch it on/off by selecting **REC ON** or **REC OFF** in step 4 above (press **ENTER**).

- 1 During the actual recording, the volume is automatically set to minimum. After the recording has finished, the record timer is canceled.
 - You cannot have the record timer and the wake-up timer set at the same time.
- 2 For example, if you select the tuner, tune in the station you want to record (see Listening to the radio on page 20).

Audio Settings and Video Adjust menu

Audio Settings menu

The Audio Settings menu offers features for adjusting the way discs sound.

1 Press HOME MENU and select 'Audio Settings' from the on-screen display.



2 Select and change settings using ↑/↓/←/
→ and ENTER.

Audio DRC

 Settings: High, Medium, Low, Off (default)

When watching Dolby Digital DVDs at low volume, it's easy to lose the quieter sounds completely—including some of the dialog. Switching Audio DRC (Dynamic Range Control) to on can help by bringing up the quieter sounds, while controlling loud peaks.

How much of a difference you hear depends on the material you're listening to. If the material doesn't have wide variations in volume, you may not notice much change.¹

Virtual Surround

EV5DVD only

• Settings: On, Off (default)

Switch on Virtual Surround to enjoy realistic surround sound effects from just two speakers.²


Video Adjust menu

From the Video Adjust screen you can adjust various settings that affect how the picture is presented.

1 Press HOME MENU and select 'Video Adjust' from the on-screen display.



2 Make settings using $\uparrow/\downarrow/\leftarrow/\Rightarrow$ and ENTER.



You can adjust the following settings:

- **Sharpness** Adjusts the sharpness of edges in the picture (**Fine**, **Standard**, **Soft**)
- Brightness Adjusts the overall brightness (-20 to +20)

- Audio DRC is only effective with Dolby Digital audio sources.
- The effect of Audio DRC also depends on your speakers and settings.
- 2 96 kHz Linear PCM audio is automatically downsampled to 48 kHz if Virtual Surround is switched on.
 - How good the surround effect is varies with the disc.

Audio Settings and Video Adjust menu

- Contrast Adjusts the contrast between light and dark (-16 to +16)
- **Gamma** Adjusts the 'warmth' of the picture (**High**, **Medium**, **Low**, **Off**)
- **Hue** Adjusts the red/green balance (**Green 9** to **Red 9**)
- Chroma Level Adjusts how saturated colors appear (-9 to +9)

Adjust the Brightness, Contrast, Hue and Chroma Level settings using ←/→.

Brightness min |||||||||,..., max 0

3 Press ENTER to return to the Video Adjust screen, or HOME MENU to exit.

Chapter 15 Initial Settings menu

Using the Initial Settings menu

The Initial Settings menu provides audio and video output settings, parental lock settings, and display settings, among others.

If an option is grayed out it means that it cannot be changed at the current time. This is usually because a disc is playing. Stop the disc, then change the setting.

- Press DVD/CD.
- With playback stopped, press HOME MENU and select 'Initial Settings'.

Initial Settings

Use $1/\sqrt{-}$ and ENTER to select the setting and option you want to set.

All the settings and options are explained on the following pages. 1

Video Output settings

| Setting | Option | What it means |
|--|------------------|---|
| TV Screen (See also Using the | 4:3 (Letter Box) | Set if you have a conventional 4:3 TV. Widescreen movies are shown with black bars top and bottom. |
| language code list on page 58.) | 4:3 (Pan & Scan) | Set if you have a conventional 4:3 TV. Widescreen movies are shown with the sides cropped so that the image fills the screen. |
| | 16:9 (Wide) | Set if you have a widescreen TV. |
| Component Out (See also Connecting using the component video output on page 11.) | Interlace | Set if your TV is not compatible with progressive scan video. |
| | Progressive | Set if your TV is compatible with progressive scan video (see your TV's instruction manual for details). Press ENTER once more to confirm (or RETURN to cancel). Note that progressive scan video is only output from the component video jacks. |

Language settings

| Setting | Option | What it means |
|----------------|------------------------|---|
| Audio Language | English | If there is an English soundtrack on the disc, it is played. |
| | Languages as displayed | If there is a language selected on the disc, it is played. |
| | Other Language | Select to choose a language other than the ones displayed (see <i>Using the language code list</i> on page 58). |

- In the table, the default setting is shown in **bold**: other settings are shown in *italics*.
- Some settings, such as TV Screen, Audio Language and Subtitle Language may be overridden by the DVD disc. Often these settings can also be made from the DVD disc menu.
 - The Component Out setting only needs to be set if you have connected this player to your TV using component video.

Initial Settings menu

| Setting | Option | What it means |
|----------------------|------------------------|---|
| Subtitle Language | English | If there are English subtitles on the disc they are displayed. |
| | Languages as displayed | The subtitle language selected on the disc is displayed. |
| | Other Language | Select to choose a language other than the ones displayed (see <i>Using the language code list</i> on page 58). |
| DVD Menu Language | w/Subtitle Lang. | DVD disc menus are displayed in the same language as your selected subtitle language, if possible. |
| | Languages as displayed | DVD menus are displayed in the selected language, if possible. |
| | Other Language | Select to choose a language other than the ones displayed (see <i>Using the language code list</i> on page 58). |
| Subtitle Display | On | Subtitles are displayed in your selected subtitle language. |
| | Off | Subtitles are always off by default when you play a DVD disc. |

Display settings

| Setting | Option | What it means |
|-----------------|------------------------|---|
| OSD Language | English | On-screen displays of the player are in English. |
| | Languages as displayed | On-screen displays are shown in the language selected. |
| Angle Indicator | On | A camera icon is displayed on-screen during multi-angle scenes on a DVD disc. |
| | Off | No multi-angle indication is shown. |

Options settings

| Setting | Option | What it means | |
|---------------|---------|------------------------------------|--|
| Parental Lock | - | See Parental Lock below. | |
| DivX(R) VOD | Display | See About DivX® VOD content below. | |

Parental Lock

• Default level: **Off**; Default password: *none*; Default Country/Area code: **us (2119)**

To give you some control over what your children watch on your DVD player, some DVD-Video discs feature a Parental Lock level. If your player is set to a lower level than the disc, the disc won't play.

Some discs also support the Country/Area Code feature. The player does not play certain scenes on these discs, depending on the Country/Area Code you set.


Registering a new password

Register a password to change the Parental Lock level or enter a Country/Area code.¹

- Not all discs use Parental Lock, and will play without requiring the password first.
- If you forget your password, you'll need to reset the player to register a new password. (see Resetting the system on page 54).

Initial Settings menu

Select 'Password'.



2 Use the number buttons to input a 4-digit password then press ENTER.

Changing your password

To change your password, confirm your existing password then enter a new one.

- 1 Select 'Password Change'.
- 2 Input your existing password, then press ENTER.
- 3 Enter a new password and press ENTER.

Setting/changing the Parental Lock

- 1 Select 'Level Change'.
- 2 Use number buttons to enter your password, then press ENTER.
- 3 Select a new level and press ENTER.
 - Press ← repeatedly to lock more levels (more discs will require the password); press → to unlock levels. You can't lock level 1.

Setting/changing the Country/Area code

You can find the *Country/Area code list* on page 59.

- 1 Select 'Country Code'.
- 2 Input your password, then press ENTER.
- 3 Select a Country/Area code then press ENTER.

There are two ways you can do this:

- Select by code letter: Use ↑/↓ to change the Country/Area code.
- Select by code number: Press → then use the number buttons to enter the 4-digit Country/Area code.

The new Country/Area code takes effect after ejecting the disc once.

About DivX® VOD content

In order to play DivX VOD (video on demand) content on this player, you first need to register the player with your DivX VOD content provider. You do this by generating a DivX VOD registration code, which you submit to your provider.¹




Important

- DivX VOD content is protected by a DRM (Digital Rights Management) system. This restricts playback of content to specific, registered devices.
- If you load a disc that contains DivX VOD content not authorized for your player, the message **Authorization Error** is displayed and the content will not play.

Displaying your DivX VOD registration code

- 1 Press HOME MENU and select 'Initial Settings'.
- 2 Select 'Options', then 'DivX(R) VOD'.



3 Select 'Display'.

Your 8-digit registration code is displayed.

Note

Resetting the player (as described in Resetting the system on page 54) will not cause you to lose your registration code.

Initial Settings menu

Make a note of the code as you will need it when you register with a DivX VOD provider.

Playing DivX® VOD content

Some DivX VOD content may only be playable a fixed number of times. When you load a disc containing this type of DivX VOD content, the remaining number of plays is shown on-screen and you then have the option of playing the disc (thereby using up one of the remaining plays), or stopping. If you load a disc that contains expired DivX VOD content (for example, content that has zero remaining plays), the message **Rental Expired** is displayed.

If your DivX VOD content allows an unlimited number of plays, then you may load the disc into your player and play the content as often as you like, and no message will be displayed.


Speaker Distance

EV7DVD/EV9DVD model only


• Default setting: 3.0m

To get the best surround sound from your system, you should set up the speakers equal distances from your listening position.

- 1 Press HOME MENU and select 'Initial Settings'.
- 2 Select 'Speakers', then 'Speaker Distance'.



3 Use **↑**/**↓** to select a speaker.



- 4 Press → to change the speaker distance for the highlighted speaker.
- 5 Use **↑**/**↓** to change the distance.
 - When you change the distance settings of the front left (L) or front right (R) speakers, all the other speaker distances change relative to it.
 - Front left/right (L/R) speaker distances can be set from 30 cm to 9 m in 30 cm increments.¹
 - The center speaker (C) can be set from -2.1 m to 0 m relative to the front left/right speakers.
 - Surround left/right (SL/SR) speakers can be set from -6.0 m to 0 m relative to the front left/right speakers.²
 - The subwoofer (SW) can be set from -2.1 m to 0 m relative to the front left/right speakers.
- 6 Press to go back to the speaker list if you want to modify another speaker, or press ENTER to exit the Speaker Distance screen.

¹ The L and R speakers are paired; you can't set them differently.

² Make sure to set them the same distance when using Front Surround (Using Front Surround on page 24).

Chapter 16 Additional information

Optional system settings

These settings are accessed by using the System Setup menu while in standby.

- 1 Switch the system into standby.
- 2 Press SYSTEM SETUP (SHIFT+HOME MENU).
- 3 Use ←/→ to choose the setting then press ENTER.

The current setting is shown for each option as you cycle through the display. See below for a full list and description of each.

- 4 Use **↑**/**↓** to adjust the setting then press ENTER to confirm.
- 5 Repeat steps 2 to 4 to make other settings.

System Setup menu options in standby

Below are all the available settings in the setup menu. The first setting in each is the default.

System demo setting

Switches the automatic demo feature on or off¹ (this starts when you plug in for the first time):

- **DEMO ON** Switches the demo feature on.²
- **DEMO OFF** Switches the demo feature off.

Key lock setting

The Key Lock feature is useful when you've set the wake-up timer and don't want the system switched on before it activates.

- **LOCK ON** Makes the front panel buttons and controls inoperative.
- LOCK OFF Restores regular use of the front panel buttons and controls.

Clock format setting

Specifies how the clock is displayed:

- 12-HOUR Display shows 12-hour format.
- 24-HOUR Display shows 24-hour format.

Tape deck beat cut setting

Recording AM broadcasts on cassette tape can result in noisy recordings. If you experience this, change the beat cut mode.

- B.CUT 1
- B.CUT 2

TV system setting

The default setting of this system is **AUTO**, and unless you notice that the picture is distorted when playing some discs, you should leave it set to **AUTO**. If you find picture distortion with some discs, set the TV system to match your country or region's system. However, this may restrict the kinds of disc you can watch.

¹ After setting the clock, the demo mode switches off automatically. However, if you unplug the system from the wall outlet, the demo mode will revert to **DEMO ON** (and the clock will be reset).

² When the demo is turned on, SFC and other sound settings are restored to their default setting. To prevent sound settings being restored to their defaults, do not turn on the demo.

See the table for the kinds of discs compatible with each setting (AUTO, PAL and NTSC).¹

 After selecting TV SYS in step 3 above, press ENTER to change the TV system.

The TV system as follows:

- AUTO → NTSC
- NTSC → PAL
- PAL → AUTO

The system automatically switches on and you'll see the new TV system setting in the display after seeing **WELCOME**.²

| Disc | | Player setting | | |
|--|--------|----------------|-----|----------------|
| Туре | Format | NTSC | PAL | AUTO |
| DVD/Super VCD/ | NTSC | NTSC | PAL | NTSC |
| Video CD/DivX Video | PAL | NTSC | PAL | PAL |
| CD/MP3/WMA/ MPEG-4 AAC/ JPEG/no disc | _ | NTSC | PAL | NTSC or PAL |

Disc / content format playback compatibility

This player is compatible with a wide range of disc types (media) and formats. Playable discs will generally feature one of the following logos on the disc and/or disc packaging. Note however that some disc types, such as recordable CD and DVD, may be in an unplayable format.

See the *About DualDisc playback* below for more information.



Fujicolor CD

- This unit will play DVD+R/+RW discs.
- 🙎 is a trademark of Fuji Photo Film Co. Ltd.
- **PP** is a trademark of DVD Format/Logo Licensing Corporation.
- Also compatible with KODAK Picture CD.

This player supports the IEC's Super VCD standard for superior picture quality, dual soundtracks, and widescreen support.





Super Video CD (Super VCD)

Note

1 Most models of the newly developed countdown PAL TV system detect 50 Hz (PAL)/60 Hz (NTSC) and automatically switch vertical amplitude, resulting in a display without vertical shrinkage. However, in some cases, the image may appear without color. If your PAL TV does not have a V-Hold control, you may not be able to watch NTSC discs because of picture roll. If the TV has a V-Hold control, adjust it until the picture stops rolling. On some TVs, the picture may shrink vertically, leaving black bands at the top and bottom of the screen.

2 You have to switch the player into standby (press & STANDBY/ON) before each change.

About DualDisc playback

A DualDisc is a new two -sided disc, one side of which contains DVD content video, audio, etc. while the other side contains non-DVD content such as digital audio material.

The non-DVD, audio side of the disc is not compliant with the CD Audio specification and therefore may not play.

The DVD side of a DualDisc plays in this product. DVD-Audio content will not play.

For more detailed information on the DualDisc specification, please refer to the disc manufacturer or disc retailer.

Compatible formats

Disc compatibility table

Media

CD-R/RW • CD-Audio, Video CD/Super VCD, ISO 9660 CD-ROM* * ISO 9660 Level 1 or 2 compliant, CD physical format: Mode1, Mode2 XA Form1. Romeo and Joliet file systems are both compatible. Multi-session playback: No · Unfinalized disc playback: No DVD-R/RW • DVD-Video (Video mode), Video Recording (VR)*, UDF Bridge DVD-ROM * Edit points may not play exactly as edited; screen may go momentarily blank at edited points. Multi Border playback: No · Unfinalized playback: No PC-created · Discs recorded using a PC may not disc be playable due to the setting of the software used to create the disc. In these instances, check the DVD-R/RW or CD-R/RW software manual or disc boxes for more on compatibility. • Discs recorded in packet write mode are not compatible.

Compressed MPEG-1 Audio Laver 3 (MP3). audio • Sampling rates: 32 kHz / 44.1 kHz /

Compatible formats

- Windows Media Audio (WMA), MPEG-
- 48 kHz
- Bit-rates: Any (128 kbps or higher recommended)
- VBR (variable bit rate) MP3/WMA/ MPEG-4 AAC playback: No
- WMA lossless encoding: No
- DRM (Digital Rights Management) compatible: Yes (DRM-protected audio files will not play in this player).
- File extensions: .mp3, .wma, .m4a (these must be used for the player to recognize MP3/WMA/MPEG-4 AAC files)
- File structure (may differ): Up to 299 folders on a disc; up to 648 folders and files (combined) within each folder

JPEG file

Media

 Baseline JPFG and FXIF 2.2* still image files up to a resolution of 3072 x 2048.

*File format for digital still cameras

- Progressive JPEG compatible: No
- File extensions: .jpg (must be used for the player to recognize JPEG files)
- File structure (may differ): Up to 299 folders on a disc; up to 648 folders and files (combined) within each folder

About DVD+R/DVD+RW compatibility

Only DVD+R/DVD+RW discs recorded in 'Video Mode (DVD Video Mode)' which have been finalized, can be played back. However, some editing made during the recording may not be played back accurately.

About DivX

DivX is a compressed digital video format created by the DivX® video codec from DivX, Inc. This player can play DivX video files burned on CD-R/RW and DVD-R/RW/ROM discs. Keeping the same terminology as DVD-Video.

individual DivX video files are called 'Titles'. When naming files/titles on a CD-R/RW or DVD-R/RW disc prior to burning, keep in mind that by default they will play in alphabetical order.

DivX video compatibility

- Official DivX® Certified product.
- Plays all versions of DivX[®] video (including DivX[®]6) with standard playback of DivX[®] media files.¹
- File extensions: .avi and .divx (these must be used for the player to recognize DivX video files). Note that all files with the .avi extension are recognized as MPEG4, but not all of these are necessarily DivX video files and therefore may not be playable on this player.

Displaying DivX subtitle files

The font sets listed below are available for DivX external subtitle files. You can see the proper font set on-screen by setting the **Subtitle Language** (in *Language settings* on page 44) to match the subtitle file.²

Group 1: Albanian (sq), Basque (eu), Catalan (ca), Danish (da), Dutch (nI), English (en), Faroese (fo), Finnish (fi), French (fr), German (de), Icelandic (is), Irish (ga), Italian (it), Norwegian (no), Portuguese (pt), Rhaeto-Romanic (rm), Scottish (gd), Spanish (es), Swedish (sv) Group 2: Albanian (sq), Croatian (hr), Czech (cs), Hungarian (hu), Polish (pI), Romanian (ro), Slovak (sk), Slovenian (sI)

Group 3: Bulgarian (bg), Byelorussian (be), Macedonian (mk), Russian (ru), Serbian (sr), Ukrainian (uk)

Group 4: Hebrew (iw), Yiddish (ji)

Group 5: Turkish (tr)

DivX, DivX Certified, and associated logos are trademarks of DivX, Inc. and are used under license.

About MPEG-4 AAC

Advanced Audio Coding (AAC) is at the core of the MPEG-4 AAC standard, which incorporates MPEG-2 AAC, forming the basis of the MPEG-4 audio compression technology. The file format and extension used depend on the application used to encode the AAC file. This unit plays back AAC files encoded by iTunes[®] bearing the extension '.m4a'. DRM-protected files will not play, and files encoded with some versions of iTunes[®] may not play, or filenames may display incorrectly.

Apple and iTunes are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.

About WMA



The Windows Media[®] logo printed on the box indicates that this player can playback Windows Media Audio content.

WMA is an acronym for Windows Media Audio and refers to an audio compression technology developed by Microsoft Corporation. WMA content can be encoded by using Windows Media[®] Player version 7, 7.1, Windows Media[®] Player for Windows[®] XP, or Windows Media[®] Player 9 Series.

Microsoft, Windows Media, and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.

- 1 Playback of .avi video files larger than 4 GB is not possible.
- 2 For external subtitle files the following subtitle format filename extensions are supported (please note that these files are not shown within the disc navigation menu): .srt, .sub, .ssa, .smi
 - Some external subtitle files may be displayed incorrectly or not at all.
 - The filename of the movie file has to be repeated at the beginning of the filename for the external subtitle file.
 - The number of external subtitle files which can be switched for the same movie file is limited to a maximum of 10.

Using and taking care of discs DVD Video regions

All DVD Video discs carry a region mark that indicates which region(s) of the world the disc is compatible with. Your DVD system also has a region mark (on the rear panel). Discs from incompatible regions will not play in this player. Discs marked **ALL** play in any player.

Handling discs

Hold the disc by its edges when handling so as not to leave fingerprints, dirt or scratches on either side of the disc. Damaged or dirty discs can affect playback performance.

If a disc becomes marked with fingerprints, dust, etc., clean using a soft, dry cloth.



Wipe lightly from the center of the disc using straight strokes. Don't wipe the disc surface with circular strokes.

If necessary, use a cloth soaked in alcohol, or a commercially available CD/DVD cleaning kit to clean a disc more thoroughly. Never use benzine, thinner or other cleaning agents such as those designed for cleaning vinyl records.

Storing discs

Avoid leaving discs in excessively cold, humid, or hot environments (including under direct sunlight). Don't glue paper or put stickers onto the disc, or use a pencil, ball-point pen or other sharp-tipped writing instrument. These could all damage the disc.

Discs to avoid

Discs spin at high speed inside the player. If a disc is cracked, chipped, warped, or otherwise damaged, don't risk using it in your player—you could end up damaging the unit.

This unit is designed for use with conventional, fully circular discs only. Pioneer disclaims all liability arising in connection with the use of shaped discs.

Using cassette tapes

The tape of a cassette is quite easily damaged and loose tape can jam in the tape deck mechanism. If the tape has become unwound, use a pen or pencil to wind it back on to the spool.



When not using cassettes, always store in the case. Store cassettes away from magnetic fields, excessive heat, humidity, dust or oil. Before recording on a tape, wind the tape on past the leader tape (about the first 3 or 4 seconds of each side).

Tapes you should avoid


Since tapes longer than 90 minutes are so thin, they are more susceptible to jamming in the tape deck mechanism and other trouble such as irregular winding. Avoid using cassette tapes longer than 90 minutes.

Protecting your recordings

You can protect an important recording against accidental erasure by breaking the erase-protect tab(s) with a small screwdriver.



If you want to re-record on an erase-protected cassette, cover the space left by the broken tab with self-adhesive tape.



Installation and maintenance

Hints on installation

We want you to enjoy using this system for years to come, so please bear in mind the following points when choosing a location:

Do...

- ✓ Use in a well-ventilated room.
- ✓ Place on a solid, flat, level surface, such as a table, shelf or stereo rack.

Don't...

- X Use in a place exposed to high temperatures or humidity, including near radiators and other heat-generating appliances.
- X Place on a window sill or other place where the system will be exposed to direct sunlight.
- X Use in an excessively dusty or damp environment.
- X Place directly on top of an amplifier, or other component in your stereo system that becomes hot in use.
- X Use near a television or monitor as you may experience interference—especially if the television uses an indoor antenna.
- X Use in a kitchen or other room where the system may be exposed to smoke or steam.
- X Use on a thick rug or carpet, or cover with cloth—this may prevent proper cooling of the system unit.
- X Place on an unstable surface, or one that is not large enough to support all four of the system unit's feet.

Cleaning the pickup lens

The DVD player's lens should not become dirty in normal use, but if for some reason it should malfunction due to dust or dirt, consult your nearest Pioneer authorized service center. Although lens cleaners are commercially available, we do not recommend using them since some may damage the lens.

Problems with condensation

Condensation may form inside the player if it is brought into a warm room from outside, or if the temperature of the room rises guickly. Although this won't damage the player, it may temporarily impair performance. You should leave it to adjust to the warmer temperature for about an hour before switching on.

Moving the system unit

If you need to move the main unit, first remove a disc if there's one in the player, then press \circ **STANDBY/ON** on the front panel to turn the system off. Wait for **GOOD BYE** to disappear from the display, then unplug the power cord. 1 Never lift or move the unit during playback discs rotate at high speeds and may be damaged.

Screen sizes and disc formats

DVD-Video discs come in different screen aspects, ranging from TV programs, which are generally 4:3, to CinemaScope widescreen movies¹, with an aspect ratio of up to about 7:3. Televisions also come in different aspect ratios: 'standard' 4:3 and widescreen 16:9.2



Set to 4:3 (Letter Box), widescreen discs are shown with black bars top and bottom.



Set to 4:3 (Pan&Scan), widescreen discs are shown with the left and right sides cropped. Although the picture looks larger, you don't actually see the whole picture.

Resetting the system

Use this procedure to reset all system settings to the factory default. Use the front panel controls to do this.

- Switch the system into standby.
- Press and hold the (stop) button for about 7 seconds until the display shows 'MEM.CLR?'
- 3 Press the ►/II button.

All the system's settings are now reset, and you should see **WELCOME** in the front panel display.

Note

Many widescreen discs override the system's settings so that the disc is shown in letterbox format regardless of the setting.

- 2 Using the 16:9 (Wide) setting with a standard 4:3 TV, or one of the 4:3 settings with a widescreen TV, will result in distortion.
- When you watch discs recorded in 4:3 format, you can use the TV controls to select how the picture is presented. Your TV may offer various zoom and stretch options; see the instructions that came with your TV for details.
 - . Some movie aspect ratios are wider than 16:9, so even with a widescreen TV, these discs will still play in a 'letterbox' style.

Troubleshooting

Incorrect operations are often mistaken for trouble and malfunctions. If you think that there is something wrong with this component, check the points below. Sometimes the trouble may lie in another component. Investigate the other components and electrical appliances being used. If the trouble cannot be rectified even after exercising the checks listed below, ask your nearest Pioneer authorized service center or your dealer to carry out repair work.

 If the unit does not operate normally due to external effects such as static electricity disconnect the power plug from the outlet and insert again to return to normal operating conditions.

General

| Duchlam | Domada |
|--|--|
| Problem The power does not turn on. | Remedy Connect the power plug to the wall outlet. Disconnect the power plug from the outlet, and insert again. Make sure the power source is the right voltage for the AC inlet. |
| The power suddenly switches off automatically and won't switch back on for a minute or so. Also, the timer indicator is blinking. | • If the speaker cables aren't connected properly, the system has a safety feature that shuts the power off automatically. Check the speaker wires to make sure they're connected properly. If there appears to be nothing wrong, try switching the power back on after the timer indicator has been blinking for a minute or so. • If you can't seem to switch the power back on after the timer indicator has been blinking for over a minute, the unit may be malfunctioning. Take it to your nearest Pioneer authorized service center or your dealer to carry out repair work. |
| No sound is output when a function is selected. | If you're using the LINE input, make sure the component is connected correctly (see <i>Connecting auxiliary components</i> on page 12). Press MUTE on the remote control to turn muting off. Adjust the volume. |
| No image is output when watching discs. | Make sure the TV is connected correctly (see Connecting to your TV on page 11). |
| Can't operate the remote control. | Replace the batteries (see Loading the batteries on page 6). Operate within 7 m, 30° of the remote sensor on the front panel (see Range of the remote control unit on page 6). Remove the obstacle or operate from another position. Avoid exposing the remote sensor on the front panel to direct light. |
| The microphone can't be heard. | Stop the disc, then restart playback. You are only using one microphone and it's plugged into the MIC (SUB) jack. The MIC (SUB) jack can only be used if there is also a microphone plugged into the MIC (MAIN) jack. Adjust the MIC VOL. |
| Feedback noise when mic is switched on. | The mic is pointing toward the speakers. Keep the mic pointed away from the speakers. The microphone level is set too high. Turn down the mic control level. |

| Problem | Remedy |
|---|--|
| SND. DEMO shows in the display and the unit can't be controlled. | Press and hold (stop) on the front panel for about five seconds. The disc tray ejects automatically to indicate the Sound Demo mode is disabled. |
| TRAYLOCK shows in the display and the tray can't be ejected. | • Press and hold DVD OPEN/CLOSE on the front panel for about eight seconds. Then the tray can be opened/closed using DVD OPEN/CLOSE . |

DVD/CD/Video CD player

| Problem | Remedy |
|--|---|
| The disc is ejected automatically after loading. | Clean the disc and align the disc properly in the disc guide. If the region number on a DVD-video disc does not match the number on the player, the disc cannot be used (see DVD Video regions on page 52). In this case, the message "Incompatible disc region number / Can't play disc." appears on-screen. Allow time for any condensation inside the player to evaporate. Avoid using the player near an air-conditioning unit. |
| Playback is not possible. | Disc may be loaded upside down. Reload the disc with the label side face up. |
| Picture playback stops and the operation buttons cannot be used. | Press ■, then start playback again (►). Switch the power off once, then on again using the front panel ♂ STANDBY/ON button. |
| Settings are canceled. | If the power is cut during operation, settings may be canceled. |
| No picture/No color. | Check that connections are correct and that plugs are inserted fully. Check the instruction manual of the TV/monitor to make sure the TV/monitor settings are incorrect. If the Progressive setting is selected and you have used component video cables to connect a TV that is not compatible with a progressive scan signal, you will not be able to see any picture at all. With your TV connected using either the composite or S-video terminals, change the Component Out setting to Interlace (see Video Output settings on page 44). |
| Screen is stretched or aspect does not change. | • The TV Screen setting is incorrect. Set the TV Screen option to match the TV/monitor you're using (see <i>Video Output settings</i> on page 44). |
| When recorded on a VCR or passed through an AV selector, there is disturbance in the playback picture. | This system uses copy-protection technology which may prevent recording or cause picture problems when connected through a VCR or AV selector. This is not a malfunction. |
| Picture disturbance during playback or dark. | This player is compatible with Macro-Vision System copy guard. Some discs include a copy prevention signal, and when this type of disc is played back, stripes etc., may appear on some sections of the picture depending on the TV. This is not a malfunction. Discs respond differently to particular player functions. This may result in the screen becoming black for a brief instant or shaking slightly when the function is executed. These problems are largely due to differences between discs and disc content and are not malfunctions of this player. |

| Problem | Remedy |
|------------------------------|---|
| Noticeable difference in DVD | DVDs and CDs use different recording methods. This is not a |
| and CD volume. | malfunction. |

WMA/MP3/MPEG-4 AAC/JPEG discs

| Problem | Remedy |
|---|--|
| CD-ROM disc is not recognized by the system. | • Make sure that the CD-ROM was recorded using the ISO 9660 disc format. See <i>Disc compatibility table</i> on page 50 for other disc compatibility information. |
| DVD-ROM disc is not recognized. | Make sure that the DVD-ROM was recorded using the UDF bridge format. See Disc compatibility table on page 50 for more on disc compatibility. |
| Files don't show up in the Disc Navigator/ Photo Browser. | • The files on the disc must be named with the correct file extension: .mp3 for MP3 files; .wma for WMA files; .m4a for MPEG-4 AAC files; .jpg for JPEG files (upper or lower-case is OK). See <i>Disc compatibility table</i> on page 50. |
| Can't play WMA or MPEG-4 AAC files. | The files were recorded using DRM (digital rights management). This is not a malfunction. |

Tuner

| Problem | Remedy |
|---|---|
| Considerable noise in radio broadcasts. | Connect the AM antenna (see Connecting the radio antennas on page 10) and adjust the direction and position for best reception. You may also connect an additional internal or external AM antenna (refer to Connecting external antennas on page 11). Fully extend the FM wire antenna, position for best reception, and secure to a wall. You may also connect an outdoor FM antenna (see Connecting external antennas on page 11). Turn off other equipment that may be causing the noise or move it further away. |
| Auto tuning does not pick up some stations. | The radio signal is weak. Auto tuning will only detect radio stations with a good signal. For more sensitive tuning, connect an outdoor antenna. |
| Sound is mono only. | Check that the tuner is not set to FM mono (see Improving FM stereo sound on page 20). |

USB connection

| Problem | Remedy |
|--|--|
| USB mass storage device is not recognized by the system. | Make sure you have completely inserted the USB connector to this unit. Check that the memory format is FAT16 or FAT32. USB devices with an internal USB hub are not supported. |
| Can't play WMA or MPEG-4 AAC files. | The files were recorded using DRM (digital rights management). This is not a malfunction. |

| Problem | Remedy |
|---|---|
| Files don't show up in the Navigator/Photo Browser. | The files must have the correct file extension: .mp3 for MP3 files; .wma for WMA files; .m4a for MPEG-4 AAC files; .jpg for JPEG files (upper or lower-case is OK). Make sure the file permission hasn't been restricted (through a password, etc.). |

Tape deck

| Problem | Remedy |
|---|---|
| Cannot record. | Check that the cassette still has its erase-protect tabs intact, or that they are covered with self-adhesive tape (<i>Using cassette tapes</i> on page 52). |
| Sound is muffled or previous recording is still audible underneath the new one. | The tape heads may be dirty. Clean the tape heads using a head-cleaning cassette or cleaning kit. Check that you're using a Type I (normal) tape. Do not use Type II (high/CrO2) or Type IV (metal) tapes. |
| Music search does not work. | The spaces between songs may be too short for music search to work. Make sure that the tape is playing when using music search—it will not work if the tape is stopped. |

Error Messages

| Message | Description |
|-----------|---|
| KEY LOCK | This message appears when the front panel buttons are pressed when the key lock feature is active. See Optional system settings on page 48 for more on switching on/off the key lock. |
| RMODE ON | An operation is prohibited because the Recording mode is on (see Making tape recordings on page 35) when recording to the tape deck. |
| PHONES IN | An operation is prohibited because headphones are connected. |
| 96K | An operation is prohibited because the source is digital 96 kHz PCM. |
| MUTING | An operation is prohibited because the sound is muted. |
| EXIT | Appears briefly when a menu is automatically exited after a set period of inactivity. |
| USB ERR | • See Important in Using the USB interface on page 32 for more on this. |
| NO MIC | A karaoke feature is prohibited because no mic is connected. |
| MIC IN | An operation is prohibited because the mic is connected. |

Using the language code list

Some of the language options (see *Language settings* on page 44) allow you to set your preferred language from any of the 136 languages listed in the *Language code list*.

1 Select 'Other Language'.

- 2 Use ←/→ to select either a code letter or a code number.
- 3 Use **↑**/**↓** to select a code letter or a code number.

See the *Language code list* (next page) for a complete list of languages and codes.

Language code list

Language (Language code letter), Language code

Japanese (ja), 1001 English (en). 0514 French (fr), 0618 German (de), 0405 Italian (it), 0920 Spanish (es), 0519 Dutch (nl), 1412 Russian (ru), 1821 Chinese (zh), 2608 Korean (ko), 1115 Greek (el), 0512 Afar (aa), 0101 Abkhazian (ab), 0102 Afrikaans (af), 0106 Amharic (am), 0113 Arabic (ar), 0118 Assamese (as), 0119 Aymara (ay), 0125 Azerbaijani (az), 0126 Bashkir (ba), 0201 Byelorussian (be), 0205 Bulgarian (bg), 0207 Bihari (bh), 0208 Bislama (bi). 0209 Bengali (bn), 0214 Tibetan (bo), 0215 Breton (br), 0218 Catalan (ca), 0301 Corsican (co), 0315 Czech (cs), 0319 Welsh (cy), 0325 Danish (da), 0401 Bhutani (dz), 0426 Esperanto (eo), 0515

Estonian (et), 0520 Basque (eu). 0521 Persian (fa), 0601 Finnish (fi), 0609 Fiji (fj), **0610** Faroese (fo), 0615 Frisian (fv). 0625 Irish (ga), 0701 Scots-Gaelic (gd), 0704 Galician (gl), 0712 Guarani (gn), 0714 Gujarati (gu), 0721 Hausa (ha), 0801 Hindi (hi). 0809 Croatian (hr), 0818 Hungarian (hu), 0821 Armenian (hy), 0825 Interlingua (ia), 0901 Interlingue (ie), 0905 Inupiak (ik), 0911 Indonesian (in), 0914 Icelandic (is). 0919 Hebrew (iw), 0923 Yiddish (ii). 1009 Javanese (jw), 1023 Georgian (ka), 1101 Kazakh (kk), 1111 Greenlandic (kl). 1112 Cambodian (km), 1113 Kannada (kn), 1114 Kashmiri (ks), 1119 Kurdish (ku). 1121 Kirghiz (ky), 1125 Latin (la), 1201

Lingala (ln), 1214 Laothian (lo), 1215 Lithuanian (lt). 1220 Latvian (Iv), 1222 Malagasy (mg), 1307 Maori (mi), 1309 Macedonian (mk). 1311 Malayalam (ml), 1312 Mongolian (mn), 1314 Moldavian (mo), 1315 Marathi (mr), 1318 Malay (ms), 1319 Maltese (mt), 1320 Burmese (mv). 1325 Nauru (na), 1401 Nepali (ne), 1405 Norwegian (no), 1415 Occitan (oc). 1503 Oromo (om), 1513 Oriya (or), 1518 Panjabi (pa), 1601 Polish (pl). 1612 Pashto, Pushto (ps), 1619 Portuguese (pt), 1620 Quechua (gu), 1721 Rhaeto-Romance (rm), 1813 Ukrainian (uk), 2111 Kirundi (rn). 1814 Romanian (ro), 1815 Kinyarwanda (rw), 1823 Sanskrit (sa), **1901** Sindhi (sd), 1904 Sangho (sg), 1907 Serbo-Croatian (sh), 1908 Sinhalese (si), 1909

Slovak (sk), 1911 Slovenian (sl), 1912 Samoan (sm), 1913 Shona (sn), 1914 Somali (so), 1915 Albanian (sq), 1917 Serbian (sr), 1918 Siswati (ss), 1919 Sesotho (st), 1920 Sundanese (su), 1921 Swedish (sv), 1922 Swahili (sw), 1923 Tamil (ta), 2001 Telugu (te), 2005 Tajik (tg), 2007 Thai (th), 2008 Tigrinya (ti), 2009 Turkmen (tk), 2011 Tagalog (tl), 2012 Setswana (tn), 2014 Tonga (to), 2015 Turkish (tr). 2018 Tsonga (ts), 2019 Tatar (tt), 2020 Twi (tw), 2023 Urdu (ur), 2118 Uzbek (uz). 2126 Vietnamese (vi), 2209 Volapük (vo), 2215 Wolof (wo), 2315 Xhosa (xh), 2408 Yoruba (yo), 2515 Zulu (zu), 2621

Country/Area code list

Country/Area, Country/Area code, Country/Area code letter

Argentina, 0118, ar Australia, 0121, au Austria, 0120, at Belgium, 0205, be Brazil, 0218, br Canada, 0301, ca Chile, 0312, cl China, 0314, cn Denmark, 0411, dk Finland, 0609, fi France, 0618, fr Germany, 0405, de

India, 0914, in Indonesia, 0904, id Italy, 0920, it Japan, 1016, jp Korea, Republic of, 1118, kr Malaysia, 1325, my Mexico, 1324, mx Netherlands, 1412, nl New Zealand, 1426, nz Norway, 1415, no Pakistan, 1611, pk

Hong Kong, 0811, hk

Philippines, 1608, ph Portugal, 1620, pt Russian Federation, 1821, ru Singapore, 1907, sq Spain, **0519**, es Switzerland, 0308, ch Sweden, 1905, se Taiwan, 2023, tw Thailand, 2008, th United Kingdom, 0702, gb United States of America, 2119, us

Preset code list

Please note that there are cases where only certain functions may be controllable after assigning the proper preset code, or the codes for the manufacturer in the list will not work for the model that you are using.

NOKIA 632, 652

AIWA 660 **ALBA** 639 **BUSH** 647 FINLUX 655 FISHER 635, 638 **FUJITSU** 648 **FUNAI** 640, 658 GE 611, 628 **GENERAL** 629

GOLDSTAR 610, 623, 650 **GRADIENTE** 630, 657 GRUNDIG 631, 653 HITACHI 633, 634, 654, 606, 624, RCA 601, 615, 616, 617, 618, 661, TELEFUNKEN 637 ITT 642 MAGNAVOX 612

MITSUBISHI 609

NEC 659

PANASONIC 608, 622 PHILIPS 607, 656 662 SALORA 643 **SAMSUNG** 644, 646 **SANYO** 645, 621, 614 **SEI** 649

FM tuner section

SHARP 602, 619, 627 **SONY** 604 **TANDY** 641 THOMSON 636, 663 **TOSHIBA** 605, 626 VICTOR 613 **ZENITH** 603, 620 PIONEER 600, 651, 999

Specifications

| Amplifier section EV7DVD/EV9DVD model Continuous power output: Front |
|---|
| Front |
| • Disc section Digital audio characteristics DVD fs: 96 kHz, 24-bit Type DVD system, Video CD/Super VCD system and Compact Disc digital audio system Frequency response 20 Hz to 44 kHz S/N ratio |
| Cassette deck section Systems 4 track, 2-channel stereo Heads Recording/playback head x 1 |

| Antenna |
|---|
| • AM tuner section Frequency range531 kHz to 1602 kHz AntennaLoop antenna |
| Miscellaneous Power requirements Multi voltage model AC 110 V to 127 V / 220 V to 230 V / 240 V (switchable), 50 Hz / 60 Hz |
| Power consumption EV7DVD/EV9DVD model |
| Weight: DVD Tuner Deck Receiver |
| Accessories (Stereo DVD Tuner Deck) Remote control 1 Power cord 1 Video cord 1 AM loop antenna 1 FM antenna 1 Dry cell batteries (AA/R6) 2 These operating instructions |

Frequency range87.5 MHz to 108 MHz

| Speaker system • Front speakers (S-EV5V/7V/9V) Enclosure Bass-reflex bookshelf type (magnetically shielded) System 16 cm 2-way system Speakers: Woofer 16 cm cone type Tweeter 5.2 cm cone type Nominal impedance 6 Ω Frequency range 42 Hz to 20 kHz Maximum input power 100 W Dimensions | Surround speakers (S-EV9V only) Enclosure Bass-reflex bookshelf type System 16 cm 2-way system Speakers: Woofer 16 cm cone type Tweeter 5.2 cm cone type Nominal impedance 6 Ω Frequency range 42 Hz to 20 kHz Maximum input power 100 W Dimensions 100 W Dimensions 3.5 kg |
|---|---|
| 200 mm (W) x 352.5 mm (H) x 244 mm (D) Weight | Subwoofer (S-EV7V only) Enclosure Bass-reflex bookshelf type |
| $ \begin{array}{lll} \bullet & \textbf{Center speaker (S-EV7V/9V only)} \\ \textbf{Enclosure} & $ | $(magnetically shielded) \\ System$ |
| Surround speakers (S-EV7V only) Enclosure Closed-box bookshelf type System 7.7 cm 1-way system Speaker 7.7 cm cone type Nominal impedance 6 Ω Frequency range 104 Hz to 20 kHz Maximum input power 100 W Dimensions 190 mm (W) x 108 mm (H) x 96 mm (D) Weight 0.6 kg | (magnetically shielded) System |



Note

· Specifications and design subject to possible modification without notice, due to improvements.

This product includes FontAvenue® fonts licenced by NEC corporation. FontAvenue is a registered trademark of NEC Corporation.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

DRM (digital rights management) copy protection is a technology designed to prevent unauthorized copying by restricting playback, etc. of compressed audio files on devices other than the PC (or other recording equipment) used to record it. For detailed information, please see the instruction manuals or help files that came with your PC and/or software.

Manufactured under license from Dolby Laboratories. "Dolby", "Pro Logic" and the double-D symbol are trademarks of Dolby Laboratories. "DTS" and "DTS Digital Surround" are registered trademarks of Digital Theater Systems, Inc.

Published by Pioneer Corporation Copyright ©2006 Pioneer Corporation All rights reserved

PIONEER CORPORATION

4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153-8654, Japan

PIONEER ELECTRONICS (USA) INC.

P.O. BOX 1540, Long Beach, California 90810-1540, U.S.A. TEL: (800) 421-1404

PIONEER ELECTRONICS OF CANADA, INC.

300 Allstate Parkway, Markham, Ontario L3R OP2, Canada TEL: 1-877-283-5901

PIONEER EUROPE NV

Haven 1087, Keetberglaan 1, B-9120 Melsele, Belgium TEL: 03/570.05.11

PIONEER ELECTRONICS ASIACENTRE PTE. LTD.

253 Alexandra Road, #04-01, Singapore 159936 TEL: 65-6472-7555

PIONEER ELECTRONICS AUSTRALIA PTY. LTD.

178-184 Boundary Road, Braeside, Victoria 3195, Australia, TEL: (03) 9586-6300

PIONEER ELECTRONICS DE MEXICO S.A. DE C.V.

Blvd.Manuel Avila Camacho 138 10 piso Col.Lomas de Chapultepec, Mexico, D.F. 11000 TEL: 55-9178-4270

K002 A En

<06C00001> Printed in <XRB3062-A>